Catalogue

Brief ---------- 2
Installation ---------- 3
Accessories List ---------- 15

1/17

Brief

Please take the time to carefully read the instructions before installing. Please refer to the manual to determine the list of all components were packaged well. (If there have some damaged parts or missing parts, please contact the customer service department) Please refer to the installation instruction while installing.

We will do our best to provide the most effective and excellent training movements. After installing, you can only know how to use the products after you know all the functions. Please read the following instructions carefully before installation and find out the wrong steps during the installing. If still not work, please contact the distributors who sold the original factory. The code and manual will be needed.

Rubber stick

Level bar

Allen wrench

Two people

Circlip pliers

The adjustable wrench

2/17

Installation

Step 1:Joint Balance weight frame (WE) and weight (Num (WC) together;
* 2 x Hexagon socket head cap screws (HS)
Step 2:Connect the seat and weight frame (WA) into weight (Num (WC);
Step 3:Connect the seat and back;
* 4 x Hexagon socket head cap screws (HS)
* 8 x spring washer (HT) * 4 x Flat Washers (HR)
* 2 x Hexagon socket head cap screws (HS)

3/17

Installation

Step 4:connect (WC11 and (WA5);
* 4 x Hexagon socket head cap screws (HS)
* 8 x spring washer (HT) * 4 x Flat Washers (HR)
* 2 x Hexagon socket head cap screws (HS2F)
* 4 x Self-locking nuts (HN2)
Step 5:Connect the Inner and Outer Inner and outer High sideframes (WGH);
Step 6:Attach the Models Foot Pads (WJ) to the Inner and Outer High Sideframes (WGH);

4/17

Installation

Step 7:Connect the Inner and Outer High Connector (WG)
to the Inner and Outer High Side Frame (WGH) as follows:
* 4 x Hexagon socket head cap screws (HS)
* 8 x Flat Washers (HR)



5/17

Installation

Step 8:Connect the inner and outer thigh left manner arm (WGH);
* The main shaft (WGH) and the inner and outer High side frame (WGH) as following
* 2 x Hexagon socket head cap screws (HS)
* 4 x spring washer (HT) * 2 x Flat Washers (HR)
Step 9:Connect the inner and outer thigh left manner arm (WGH) with the Clamp plate (WGH);
Clamp plate (WGH) main shaft (WGH) and inner and outer High frame (WGH) as following
* 2 x Hexagon socket head cap screws (HS)
* 4 x spring washer (HT) * 2 x Flat Washers (HR)
Step 10:Connect the inner and outer High Connector (WG) with the left manner arm (WGH) and right manner arm (WGT)
as follows:
* 2 x Hexagon socket head cap screws (HS)
* 4 x spring washer (HT) * 2 x Flat Washers (HR)
Step 11:Connect the inner and outer High side (WGH) to the backrest arm (WG)
* 4 x Hexagon socket head cap screws (HS2)
* 8 x spring washer (HT2) * 4 x Flat Washers (HR2)

6/17

Installation

Step 12:Slide the two weight stack rubber pads (WGH) into the the weight stack guide rods (WGT);
Attach the two weight stack rubber pads (WGH) to the weight stack guide rods (WGT)
and place in the weight frame (WC) as follows:
* 4 x Hexagon socket head cap screws (HS)
* 8 x spring washer (HT) * 4 x Flat Washers (HR)
Route to tighten the bolts before proceeding to the next step
Step 13:Install the 50 weights stack (WGT) onto the weight stack guide rods (WGT) with the square facing up

Install Guide Block Set (WGH) onto weight stack Guide Rod (WGT);
Attach the Guide Block Set (WGH) to the Weight Stack (WGT);
Slide Guide Rod Protector Plate (WGH) onto weight stack Guide Rod (WGT);
Step 14:Connect the Inner and Outer High Connector (WG) to the Inner and Outer High Frame (WC) using the following method:
* 2 Hexagon socket head cap screws (HS8)
Route to tighten the bolts before proceeding to the next step

7/17

Installation

Step 15:Pass the cable (WGH) through the cable II (WGH) as shown in the Figure,
connect them with the left manner arm (WGT) and the right manner arm (WGT) respectively.

8/17

Installation

Step 16:Attach the cable (WGH) to the Inner and Outer High Sideframes (WGH) in the following way:
* 4 x Hexagon socket head cap screws (HS3)
* 4 x spring washer (HS2)
* 4 x Flat Washers (HR2)

9/17

Installation

Step 17:Attach the backrest (WGH) to the Inner and Outer High Sideframes (WGH) in the following way:
* 4 x Hexagon socket head cap screws (HS)
* 8 x spring washer (HT)
* 4 x Flat Washers (HR)

10/17

Installation

Step 18:Attach the backrest (WGH) to the inner and outer High side frames (WGH) as follows:
* 4 x Hexagon socket head cap screws (HS8)

Step 19:Install the 3 Mile Plate (WGT) onto the Inner and Outer High Sideframes (WGH);

11/17

Installation

Step 20:Attach the two cable pulleys (WGH) onto the Inner and Outer High Sideframes (WGH) as follows:
* 4 x Hexagon socket head cap screws (HS8)

Step 21:Install the 4 Mile Plate (WGT) onto the Inner and Outer High Sideframes (WGH);

12/17

Installation

Step 22:Slide the two thin cushion (WGH) into the two fenders (WGH);
using the Fender clamps to attach to the weight frame (WC);
Slide decorative plate (WGH) into both fenders (WGH), attach to weight frame (WC) using fender clamp

Attach the two upper shields (WGH) to the weight frame (WC) as follows:
* 4 x Hexagon socket head cap screws (HS)
Step 23:Attach the two weight stack caps (WGH) to the weight frame (WC) as follows:
* 4 x Hexagon socket head cap screws (HS)
Step 24:Pass the spare shroud top cap (WGT) to the upper shroud (WGH);

13/17

Installation

14/17

Important note

Now that the Inner and Outer High Trainer is finished, you need to make sure that the machine is level and vertical. Use the level bar to check that the frame is level and vertical. Use a hex allen key. Some floating hardware must be loosened to reassemble and fully tightened if not plumb.

Accessories List

No.	Name & Specification	Q'ty
1	weight frame	1
2	Balance weight frame	1
3	Hexagon socket head cap screws (HS+M3)	2
4	foot pad of weight frame	2
5	Inner and Outer High Connector	1
6	Hexagon socket head cap screws (HS+M3)	20
7	spring washer (18)	12
8	Flat washer (18)	20
9	Hexagon socket head cap screws (HS+M3)	6
10	Inner and outer High side frame	1
11	Inner and outer thigh connecting plate	2
12	Hexagon socket head cap screws (HS+M3)	4
13	Hexagon self-locking nut (HN2)	4
14	Flat seat foot pad	1
15	Wooden foot pad	1
16	Inner and Outer Thigh Left Manner Arm	1
17	Inner and outer thigh right manner arm	1
18	Fender	2
19	Linkage plates	1
20	Spindle	1
21	Inner and Outer Thigh Middle Axle	2

15/17

Accessories List

No.	Name & Specification	Q'ty
22	big spring washer (25)	2
23	the inner and outer thigh pads	2
24	Hexagon socket head cap screws (HS+M3)	8
25	spring washer (8)	28
26	flat washer (8)	28
27	weight stack guide rods	2
28	weight stack rubber pads	2
29	Weight frame base	2
30	Hexagon socket head cap screws (HS+M3)	4
31	weight stack	10
32	guide block set	1
33	guide rod fixing plate	1
34	weight stack pin	1
35	cable I	1
36	cable II	2
37	cushion	1
38	armrest	2
39	backrest	1
40	Hexagon socket head cap screws (HS+M3)	1
41	3D hole plug	2
42	baffle	4

16/17

Accessories List

No.	Name & Specification	Q'ty
43	side stiffener	2
44	decorative plate	1
45	upper shroud	2
46	weight stack cap	2
47	upper shroud top cap	1

Note: Pre-assembled parts not listed in this table.

17/17