

Table of Contents

Introduction ---------- 2
Installation ---------- 3
Accessories List ---------- 11

Introduction

Please take some time to read this instruction carefully before installation. Please refer to the lists in the instruction manual to confirm the integrity and count of all parts (if any part is missing or damaged during transportation, please call our company for after-sales immediately). When installing, please follow instructions for proper installation of equipment.

This device is designed to provide the smoothest and most efficient workout possible. Before installation, you need to understand all the functions to use it correctly. If you find any problems during use, you should stop using it immediately to avoid bodily injury and equipment damage. And timely refer to the relevant instructions to check the reasons, if you can't solve it, please call our after-sales service. After reading all the instructions carefully, please continue :

Rubber Stick

Level

Allen Wrench

Two People

Circlip Plier

Adjustable Wrench

Installation

Step 1: Connect the Lower Shield (M2) to the Housing Frame (M1) with the following

- 6 x Spring Washer Head Cap Screws (M15)

Step 2: Connect the Glute Trainer Frame Base (M4) to the Housing Frame (M1) with the following :

- 4 x Hexagon Socket Head Cap Screws (M5)
- 8 x Spring Washer (M6)
- 8 x Flat Washers (M7)
- 2 x Hexagon Socket Head Cap Screws (M8)

Step 3: Path the 2 Weight Stack Feet Covers (M9) on the Housing Frame (M1)

Attach 1 Flat Heat Foot Pad (M10) to the Glute Trainer Frame Base (M4)

Installation

Step 4: Connect the Glute Trainer Main Frame (M11) to the Glute Trainer Frame Base (M4) with the following :

- 4 x Hexagon Socket Head Cap Screws (M12)
- 4 x Spring Washer (M6)
- 4 x Flat Washers (M7)
- 4 x Hexagon Socket Head Cap Screws (M12)

Installation

Step 5: Connect Glute Trainer Arm (M14), Aluminum Cap (M15) and Spindle Bracket (M13) with the following :

- 1 x Hexagon Socket Flat Head Cap Screws (M16)

Step 6: Put 2 Heat Pad Foot Cover (M10) on the Glute Trainer Spindle Bracket (M13)

Installation

Step 7: Connect the Glute Trainer Spindle Bracket (M13) to the Glute Trainer Frame Base (M4) and Housing Frame (M1) with the following :

- 2 x Hexagon Socket Head Cap Screws (M17)
- 6 x Spring Washer (M6)
- 6 x Flat Washers (M7)
- 4 x Hexagon Socket Head Cap Screws (M8)



Installation

Step 8: Slide the two Weight Stack Rubber Pads (M18) to the Guide Rods (M27).

Connecting the two Hexagon Socket Screws Head to the two Guide Rods (M27) and place into the Housing Frame (M1) with the following : • 2 x Hexagon Socket Head Cap Screws (M20)

- 2 x Spring Washer (M21)
- 2 x Flat Washers (M22)

Tighten the bolts with a wrench before proceeding to the next step

Step 9: Install the 16 pcs of Weight Stacks (M23) to the Guide Rods (M27), keep the spacers facing up.

Connect the Top Guide Rod Fixed Plate (M24) to the Guide Rods (M27), Insert the Weight Stack Pin (M26) into the Weight Stacks (M23). Slide the Guide Rod Fixed Plate (M24) to the Guide Rods (M27), Install the Guide Rod Fixed Plate (M25) to the Housing Frame (M1) with the following

- 4 x Hexagon Socket Head Cap Screws (M28)

Tighten the bolts with a wrench before proceeding to the next step

Installation

Step 10: Thread the Cable (M22) as shown in the picture, Cable Connection Diagram need to be disassembled and then re-installed

Please pay attention : Three Pulleys should be installed simultaneously with the Cable (M22)

Step 11: Connect the 120 Pulley (M30), Pulley Box (M29), Pulley Box Bushing (M31) and Glute Trainer Spindle Bracket (M13) with the following :

- 1 x Pulley Shaft (M32)

Step 12: Connect one end of the Cable (M22) to the Glute Trainer Arm (M14) first, and then connect the other end to the Housing Frame (M1)



Installation

Step 13: Slide the two Front Bearings (M33) into the two Housing Stripe (M35), using the Baffle Plate to attach to the Housing Frame (M1)

Step 14: Slide the Cable (M22) into the two Front Bearings (M33) and attach to the Housing Frame (M1) using the Baffle Plate, Connect the two Top Covers (M35) to the Housing Frame (M1) with the following :

- 8 x Hexagon Socket Head Cap Screws (M36)

Step 15: Connect the Upper Shield Top Cover (M37) and Upper Cage (M38) to the Housing Frame (M1) with the following :

- 2 x Hexagon Socket Head Cap Screws (M1)

Step 16: Snap the Upper Shield Top Cover (M37) to the Top Cover (M35)

Installation

Important notice

Now the (M28) is assembled, you need to make sure your setup is level and vertical,Use a level to check that the guide rods are vertical in both directions.Some frame hardware must be

Accessories List

No.	Name and Specifications	Quantity
1	Housing Frame	1
2	Lower Shield	1
3	Hexagon Socket Head Cap Screws (M5*16)	12
4	Glute Trainer Frame Base	1
5	Hexagon Socket Head Cap Screws (M8*25)	4
6	Spring Washers (M15)	15
7	Flat Washers (M15)	15
8	Hexagon Socket Head Cap Screws (M10*25)	6
9	Weight Stack Foot Cover	2
10	Flat Heat Foot Pad	3
11	Glute Trainer Main Frame	1
12	Hexagon Socket Head Cap Screws (M10*120)	1
13	Hip Stripe Spindle Bracket	1
14	Glute Trainer Arm	1
15	Aluminum Cap	1
16	Hexagon Socket Flat Head Screws (M10*25)	1
17	Universal Height Stack Guide Rod	2
18	Weight Stack Rubber Pad	2
19	Housing Frame Base	2
20	Hexagon Socket Head Cap Screws (M8*20)	4
21	Spring Washers (M10)	2

Accessories List

No.	Name and Specifications	Quantity
22	Flat Washers (M10)	2
23	Weight Stacks	16
24	Guide Rod	1
25	Guide Rod Fixed Plate	1
26	Weight Stacks Pin	1
27	Cable	1
28	120 Pulley	1
29	Pulley Box	2
30	Pulley Box Bushing	2
31	Pulley Shaft	1
32	Bearings	4
33	Weight Stack Housing Stripe	2
34	Weight Stack Trim Plate	1
35	Top Cover	2
36	Weight Stack Frame Upper Cap	2
37	Upper Shield Top Cover	1

NOTE: Pre-assembled parts are not listed in this table.