catalogue 2
Installation 3
accessories list 18

catalogue

Please take the time to read this instruction carefully before installation. Please refer to the various links in the manual to confirm the integrity and quantity of all parts (if there are parts missing or damaged during transportation, please call us before start service department for disconnection). Please install the equipment correctly according to the instructions. Improper installation will affect the performance of the equipment and may cause injury. If you have any questions, you need to understand all functions or use it incorrectly. If you find any problems during use, you should stop using it immediately to avoid physical injury and equipment damage. Please keep the manual properly for maintenance. Please do not throw away the manual. Please contact us after-sale service. After reading the instructions carefully, please

Rubber mat
Level
Bumper wrench
Tee screws
Flathead screwdriver
Adjustable wrench

3/18

Installation

Step 1:Place the seat shoulder bracket (NO. 4#) down below correctly as the picture.

4/18

Installation

Step 2:Connect the counterweight lower panel (NO.5) to the counterweight frame (NO.1) by the following way:

2 x M10 Bumper socket head screws (NO.1)

Step 3:Connect the shoulder seat frame (NO.3) to the shoulder frame (NO.4) and the shoulder seat frame (NO.3) to the seat frame (NO.2) by the following way:

4 x M10 Bumper socket head screws (NO.1)
4 x M10 Flat washers (NO.2)
4 x M10 Nylock nuts (NO.3) (* 4 x Flat washers (NO.2)

Step 4:Connect the two weight stack bars (NO.6) to the weight stack frame (NO.1) and connect the two front bars (NO.8) to the shoulder bracket (NO.4).

5/18

Installation

Step 5:Connect the middle (NO.9) to the rear (NO.10) by the following way:
4 x M10 Bumper socket head screws (NO.1)
4 x M10 Flat washers (NO.2)
Tighten the screws with a wrench before proceeding to the next step.

6/18

Installation

Step 6:Connect the seat (NO.11) to the seat frame (NO.2) by the following way:
4 x M10 Bumper socket head screws (NO.1)
4 x M10 Flat washers (NO.2)
Tighten the screws with a wrench before proceeding to the next step.

7/18

Installation

Step 7:Attach the back pad (NO.12) and back pad (NO.13) to the shoulder seat (NO.3) by the following way:
4 x M10 Bumper socket head screws (NO.1)
Tighten the screws with a wrench before proceeding to the next step.

Step 8:Connect the V-grip plug (NO.7) to the weight stack (NO.6) by the following way:

8/18

Installation

Step 9:Locate the lower lever arm (NO.)(NO.)(NO.) and place it in the platform surface.

Step 10:Connect the lever arm to axle (NO.) and the two axle covers (NO.) to the lever arm (NO.) in the following way:
2 x M10 Bumper socket head screws (NO.)
2 x M10 Bumper socket head screws (NO.)
Tighten the screws with a wrench before proceeding to the next step.

Step 11:Install the two link plate (NO.) to the lever arm (NO.).

9/18

Installation

Step 12:Connect the lever arm assembly (NO.) to the shoulder seat frame (NO.) in the following way:
2 x M10 Bumper socket head screws (NO.1)
2 x M10 Flat washers (NO.2)
Tighten the screws with a wrench before proceeding to the next step.

Step 13:Connect the lever arm assembly (NO.) to the seat frame (NO.2) by the following way:



10/18

Installation

Step 14:Slide the two rubber weight pads (NO.) onto the two guide rods (NO.).
Step 15:Connect the two guide rods (NO.) to the weight stack (NO.) and tighten them into the weight stack (NO.) by the following way:
4 x M10 Bumper socket head screws (NO.1)
4 x M10 Flat washers (NO.2)
Tighten the screws with a wrench before proceeding to the next step.

Step 16:Install the 45 machine(NO.) (NO.) onto the guide rods (NO.) and tighten them into the weight stack (NO.) by the following way:
4 x M10 Bumper socket head screws (NO.1)
4 x M10 Flat washers (NO.2)
Tighten the screws with a wrench before proceeding to the next step.

11/18

Installation

Step 17:Attach the two 45 machine (NO.) to the counterweight frame using the following method:
4 x M10 Bumper socket head screws (NO.1)
4 x M10 Flat washers (NO.2)
4 x M10 Nylock nuts (NO.3)

Connect the three 45-bar bars (NO.) to the shoulder frame (NO.) and the lever arm assembly (NO.) by the following way:
4 x M10 Bumper socket head screws (NO.1)
4 x M10 Flat washers (NO.2)
Note:Four bolts are not installed temporarily for the bolt hole (NO.).

Step 18:Connect the two 45 machine (NO.) to the counterweight frame (NO.) by the following way:

12/18

Installation

Step 19:Slide the two hip pad (NO.) onto the two bumper (NO.) and attach to the counterweight frame (NO.) using the handle grooved plate.
Step 20:Connect the two bumper (NO.) to the pulley (NO.) and attach to the counterweight frame (NO.) using the handle grooved plate.
Step 21:Connect the two bumper (NO.) to the counterweight frame (NO.) using the following way:
4 x M10 Bumper socket head screws (NO.1)
4 x M10 Flat washers (NO.2)

Attach the upper cover to the (NO.) to the counterweight frame (NO.) as follows.
4 x M10 Bumper socket head screws (NO.1)

13/18

Installation

Important Tips:
Use Tool for Nut Shoulder Press to assemble, the tool is like a spanner with a hole in the middle, the hole is for the nut to go through, the tool is for the nut to be held in place while the bolt is tightened.

14/18

Accessories List

No.	Name and specifications	Pcs
A	Shoulder seat cover	1
B	Bumper socket head screws (M10X65)	2
C	Flat washers (20)	2
D	Nylon washers (20)	2
E	Bumper socket head screws (M10X65)	2
F	Counterweight sock	1
G	Shoulder seat cover	1
H	Arm Cross	1
I	Counterweight lower panel	1
J	Bumper socket head screws (M10X65)	4
K	Weight sock front seat	1
L	Front seat foot pad	1
M	Screws	1
N	Lubricant	1
O	Bumper socket head screws (M10X65)	4
P	Flat washers (20)	4
Q	Nylock nuts (M10)	4
R	Bumper socket head screws (M10X65)	4
S	Back pad	1
T	Back pad	1

15/18

Accessories List

No.	Name and specifications	pcs
U	Bumper socket head screws (M10X65)	4
V	Arm axle plug	2
W	Arm Cross	2
X	Arm bushing	4
Y	Axle pad	2
Z	Counterweight connecting pad	2
AA	Aluminum weight guide rod	2
AB	Counterweight rubber pad	2
AC	Counterweight sock bar	2
AD	Bumper socket head screws (M8X20)	10
AE	Weight sock 3D	1
AF	Grip tube cap	2
AG	Quick set tube plate	1
AH	Bumper socket head screws (M8X20)	2
AI	Quick set tube plate	1
AJ	Set pin	1
AK	Pull pin	1
AL	Flat washers (20)	1
AM	Bumper set bushing nuts (M8)	1

16/18

Accessories List

No.	Name and specifications	pcs
AN	Axle nut	1
AO	Axle	1
AP	Counterweight spacer decorative strip	2
AQ	Counterweight spacer decorative strip	2
AR	Counterweight spacer plate	2
AS	Spacer pivot sleeve	1
AT	Spacer sleeve decorative	2
AU	Bumper socket head screws (M8X20)	2

Note:The accessories parts are not listed in this table.

17/18