catalog

Introduction 2
Assembly 3
Packing Details 10

Introduction

Please take the time to read these instructions carefully before installation. Please refer to the instruction manual to assemble.

It is professional and a quantity of quality of quality and to ensuring to be engaged during transportation, please call our professionals.

Understand the after-sales instructions. When installing, please install the equipment correctly according to the instructions.

Understanding is designed to provide the conditions and musculoskeletal exercise movements provided. After installation, you

Can understand the functions to use it correctly. If you find problems during use, you should stop using it.

Environment

Avoid exposure to sun and excessive temperature. Not anti-corrosive fabric to the exposed environment to extend the lifespan. Other

rubber mat
spirit level
allen wrench
Tool package
crimp pliers
Adjustable wrench

Assemble

Step 1 : Install the four foot pads (3) on the four positions of the stiffener (2) and the main frame (1).

Step 2 : Join the Reclining seatback(4) connect the bottom flame (1), left frame (2), right frame (3), and connecting frame (5).

2# M10*75# hexagon socket head screws - 12
8# M10 flat washer - 12
8# M10 spring washer - 12
8# M10 hex nuts - 12
Tighten the hexagon socket head screws with 5mm hex key.

Assemble

Step 3 : Connect the left armrest frame (6) to the main frame (1) using the big hex key wrench.

Use the same method to connect the right armrest frame (7) to the right frame (3).

4# M10*30 hexagon socket head screws - 8
8# M10 flat washer - 8
4# M10 hex washer - 4
Tighten the hexagon socket head screws with 5mm hex key.

Step 4 : Put the fitting rod(8) to connect the push-up post frame (11) to the left armrest frame (6) and right armrest frame (7).

2# M10*30 hexagon socket head screws - 4
4# M10 flat washer - 4
2# M10 hex washer - 2
Tighten the hexagon socket head screws with 5mm hex key.

Assemble

Step 5 : Put the fitting rod(9) to connect the push-up post frame (11) to the left armrest frame (6) and the left seat frame (10) and then connect the right armrest frame (7) to the right seat frame (12).

2# M10*30 hexagon socket head screws - 4
4# M10 flat washer - 4
2# M10 hex washer - 2
Tighten the hexagon socket head screws with 5mm hex key.

Assemble

Step 6 : Use the fitting rod(9) to connect the backrest frame (13) to the left seat frame (10) and the right seat frame (12).

2# M10*30 hexagon socket head screws - 4
4# M10 flat washer - 4
2# M10 hex washer - 2
Tighten the hexagon socket head screws with 5mm hex key.

Assemble

Step 7 : Use the fitting rod(9) to connect the backrest frame (13) to the left seat frame (10) and the right seat frame (12).

2# M10*30 hexagon socket head screws - 4
4# M10 flat washer - 4
2# M10 hex washer - 2
Tighten the hexagon socket head screws with 5mm hex key.

Assemble

Step 8 : Install the cushion kit (14) on the left seat frame (10) and the right seat frame (12) using the Phillips Screwdriver.

4# M5*10 Phillips flat head screws - 4

Step 9 : Use the fitting rod(9) to connect the support frame (15) to the left seat frame (10) and the right seat frame (12).

2# M10*30 hexagon socket head screws - 4
4# M10 flat washer - 4
2# M10 hex washer - 2
Tighten the hexagon socket head screws with 5mm hex key.

Assemble

Step 10 : Place the iron cushion board (16) on the left seat frame (10) and the right seat frame (12).

Step 11 : Install the counter-weight (18) onto the guide rod (17), and the spacer having a pin-hole

inserting a pin-hole into one of the pin-holes of the counter-weight (18) and then inserting the pin into the pin-hole of the lower end of the guide rod (17), and then fixing the pin with a split pin (19).

Install the guide rod (17) onto the push-up post frame (11) using the big hex key wrench.

4# M10*30 hexagon socket head screws (21)
4# M10 flat washer (22)
Install the guide rod (17) onto the push-up post frame (11) using the big hex key wrench.

Assemble

Step 12 : Slide the iron-chain (20) over the iron-hook (23) and connect the weight frame (17) using the hooke connects plate (24).

Place the square pad (25) on the top of the frame (17) and connect the weight frame (17) using the hooke clamps (26).

Attach the 4 plastic gasket (27) to the weight frame using ~ 11.

Install the hexagon socket head screws (28) onto the square pad.

Assemble

Step 13 : Slide the iron-chain (20) over the iron-hooke (29) and connect the weight frame (17) using the hooke connects plate (24).

Place the square pad (30) on the top of the frame (17) and connect the weight frame (17) using the hooke clamps (31).

Attach the 4 plastic gasket (32) to the weight frame using ~ 11.

Install the hexagon socket head screws (33) onto the square pad.

Assemble

Weight Stack Guide

Take Note: The Assisted Pull-up/Dip/Chin Up is assembled, you need to make a decision to determine the weight of the counterweight. Please refer to the following table to choose the weight of the counterweight. Please refer to the following table to choose the weight of the counterweight.

Standing Assisted Chin/Dip Packing list

序号	名称	图片	数量
1	chassis		1
2	left shaft		1
3	Right shaft		1
4	Connecting frame		1
5	Tube plate		1
6	left armrest		1
7	Right armrest		1
8	Rod up and down		1
9	Connecting rod L=210mm		2
10	Backrest		1

序号	名称	图片	数量
11	Left seat frame		1
12	Right seat frame		1
13	Iron plate		1
14	Cushion Cloth		1
15	Support frame		1

序号	名称	数量
A	Hexagon socket head screw M10*30	20
B	Spring washer M10	12
C	Flat washer M10	16
D	Hexagon socket head screw M10*90	4
E	Hexagonal nut M10	4
N	Hexagon socket head screw M10*80	4

NOTE: For accessibility tools, see the tools in the table.