618UG Installation Guide

Shoulder Press

Catalog

Introduction ---------- 2

Assembling ---------- 3

Accessory List ---------- 16

1/16

Introduction

Please take the time to carefully read the instructions before installing.Please refer to the manual to determine the list of all components were packaged well, . If there have some parts missing, please contact us immediately to avoid unnecessary loss. Assembly!Please refer to the installation instruction while assembling.

This device designed to provide the most effective and efficient workout.Please read this manual carefully to learn how to use the product after you know all the functions. If there is any question, please check the installation instruction again. If you still have problem in the assembling, if still not work, please contact the distributors authorized by original factory. The code and manual will be needed.

Tools

Rubber End
Level Ruler
Hexagonal wrench
More than 2 person
Spring Clamp
Adjustable wrench

2/16

Assembling

Step 1: Place the shoulder pushing frame (M2) shown below upright on the ground plane.

3/16

Assembling

Step 2: Connect the push-shoulder attachment bracket (M6) to the counterweight bracket (M7) and the push-shoulder side bracket (M1) using the following method.

* 8 x Hexagon socket sleeve head screws (M4)
* 8 x Spring washers (M4) ---- 8 x Flat washers (M4)
* 16 x Spring washers (M4) ---- 16 x Nut washers (M4)

Step 3: Connect the counterweight lever shroud (M10) to the counterweight frame (M7) using the following method.

* 4 x Hexagon socket sleeve head screws (M4)

Step 4: Install the the counterweight frame lever (M12) to the counterweight frame (M7) Install two flywheel protection pad (M13) to the push-shoulder side frame (M2)

4/16

Assembling

Step 5: Connect the seating (M14) to the push-shoulder side frame (M2) using the following method.

* 4 x Hexagon socket sleeve head screws (M10)
* 4 x Spring washers (M4)
* 4 x Flat washers (M4)

Tighten the bolt with a wrench, then proceed to the next step

5/16

Assembling

Step 6: Connect the seat (M14) to the push-shoulder side frame (M2) using the following method.

* 4 x Hexagon socket sleeve head screws (M10)
* 4 x Spring washers (M4)
* 4 x Flat washers (M4)

Tighten the bolt with a wrench, then proceed to the next step



6/16

Assembling

Step 7: Connect the backrest pad (M15) and back pad (M17) with the push shoulder side frame (M2) using the following method.

* 8 x Hexagon socket sleeve head screws (M10)
* 8 x Spring washers (M4)

Tighten the bolt with a wrench, then proceed to the next step

Step 8: Install the one 20-hole plate (M20) into the push-shoulder side frame (M2).

7/16

Assembling

Step 9: Fixed the lower force arm (M22, M23, M24) to place on the platform surface.

Step 10: Connect the curved push (M25) and the pushing shoulder balance weight (M26) to the force arm (M22) using the following method

* 4 x Hexagon socket sleeve head screws (M10)
* 4 x Spring washers (M4)

Tighten the bolt with a wrench, then proceed to the next step

Step 11: Install two 20-hole plate (M20) to the counterweight (M26).

8/16

Assembling

Step 12: Connect the force arm set (M8) to the shoulder push side brace (M2) using the following method. Then proceed to the next step

* 4 x Hexagon socket sleeve head screws (M10)
* 4 x Spring washers (M4)

Tighten the bolt with a wrench, then proceed to the next step

Step 13:Install two hole plugs (M28) to the force arm set (M8).



9/16

Assembling

Step 14: Slide the two counterweight rubber pads (M31) onto the two guide bars (M30). Connect the two counterweight bases (M32) to the two guide bars (M30) and the counterweight frame (M7) using the following method.

* 4 x Hexagon socket sleeve head screws (M10)
* 4 x Spring washers (M4) ---- 4 x Flat washers (M4)

Tighten the bolt with a wrench, then proceed to the next step



10/16

Assembling

Step 15: Connect the two 90 wire sheaths (M33) to the counterweight frame (M7) using the following method.

* 2 x Wire sheaths (M33) ---- 2 x Flat washers (M4)
* 2 x Nut washers (M4) ---- 2 x Flat washers (M4)

Step 16: Connect the counterweight frame (M7) to the push-shoulder side frame (M2) and the force arm set (M8) using the following method.

* 4 x Hexagon socket sleeve head screws (M10)
* 4 x Flat washers (M4) ---- 4 x Spring washers (M4)

Note that these spacers are installed in tandem with the wire rope (M36).

Step 17: Connect the wire rope (M36) to the force arm set (M8) and counterweight frame (M7), attach the M13 bolt and nut of the wire rope (M36) to the push shoulder side frame (M2).

11/16

Assembling

Step 18:Slide the two big sliding (M39) into the two baffles (M40) and attach to the counterweight frame (M7) using the baffle pressure plate. Slide the two small sliding (M41) into the two baffles (M40) and attach to the counterweight frame (M7) using the baffle pressure plate. Attach the two upper shrouds (M42) to the counterweight frame (M7) using the following method.

* 4 x Hexagon socket sleeve head screws (M10)

Connect the two cover of the upper shroud (M43) to the two upper shrouds (M42). Connect the two counterweight cross plug covers (M44) to the counterweight frame (M7) using the following method.

* 4 x Hexagon socket sleeve head screws (M10)

12/16

Assembling

Important Tips

Now that the shoulder press is assembled, you need to take a moment to make sure your unit is horizontal and vertical. Use a level to check that the guide bar is vertical in both directions. Also, check that the seat and back pad are level. Hardware must be tightened and the bolts reassembled and tightened.

13/16

Accessory List

NO	Name and specification	Quantity
1	Push shoulder side stand	1
2	Hexagon socket sleeve head screws (M10*65)	2
3	Spring washers (M8)	12
4	Flat washers (M8)	15
5	Hexagon socket sleeve head screws (M10*65)	8
6	Counterweight rack	1
7	shoulder press connection frame	1
8	Power arm set	1
9	Counterweight lower shroud	1
10	Hexagon socket sleeve head screws (M4*16)	12
11	Counterweight frame foot pads	2
12	Flat Steel Footbed	2
13	Nuts	5
14	Cushion	1
15	Hexagon socket sleeve head screws (M4*65)	6
16	Spring washers (M)	6
17	Flat washers (M)	6
18	Hexagon socket sleeve head screws (M10*65)	4
19	Head Cushion	1
20	Back Pad	1

14/16

Accessory List

NO	Name and specification	Quantity
21	Hexagon socket sleeve head screws (M4*40)	6
22	20-hole plug	4
23	Power arm set	1
24	Curved Bar	2
25	Push shoulder balance weight	1
26	Internal counterweight pad	2
27	Counterweight rubber pad	2
28	Counterweight stand base	2
29	Hexagon socket sleeve head screws (M8*65)	4
30	Counterweight blocks	16
31	Guide block set	1
32	Guide rod fixing plate	1
33	Counterweight block plate	1
34	shoulder press seat	1
35	M8 Wire Rope	2
36	Wire sheet 02	1
37	Flat washers (12)	3
38	Hexagonal self-locking nuts (M16)	3

15/16

Accessory List

NO	Name and specification	Quantity
39	120 wire sheets	3
40	Bolts	4
41	Counterweight source decorative strips	2
42	Counterweight source decorative plate	1
43	Counterweight upper shroud	1
44	Upper shroud top cover	1
45	Counterweight cross plug cover	2

Note: Pre-assembled parts are not listed in this table.

16/16