Table of Contents

Introduction ---------- 2
Installation ---------- 3
Accessories List ---------- 16

1/16

Introduction

Please take some time to read this instruction carefully before installation. Please refer to the lists in the instruction manual to confirm the integrity and quantity of all parts (if any parts are missing or damaged, please contact us or your nearest dealer for assistance immediately). When installing, please follow instructions for proper installation of equipment.

This device is designed to provide the smoothest and most efficient workout possible. After installation, you need to understand all the functions to use it correctly. If you find any problems during use, please stop using the equipment and to avoid bodily injury and equipment damage. And timely refer to the relevant instructions to check the reasons, if you can't solve the problem, please contact customer service for resolution. And the instructions needed in this manual:

Rubber Stick

Level

Allen Wrench

Two People

Circlip Plier

Adjustable Wrench

2/16

Installation

Step 1: The three-headed lower crimp frame (M1)

3/16

Installation

Step 2: Connect the three-headed lower connection frame (M2) with the counterweight frame (M3) and the three-headed lower crimp frame (M1) by following method:

* 4 x Hexagon socket cheese head screws (M8)
* 4 x Hexagon socket cheese head screws (M6)

Step 3: Connect the three-headed lower connection frame (M2) and the counterweight frame (M3) using the following method:

* 4 x Hexagon socket cheese head screws (M8)

Step 4: Install the two-connected counterweight foot (M12) to the counterweight frame (M3) by using:

* 4 x Hexagon socket cheese head screws (M12) to the three-headed lower crimp frame (M1)



4/16

Installation

Step 5: Connect the seat (M13) to the three-headed lower connection frame (M2) by following method:

* 4 x Hexagon socket cheese head screws (M10)
* 4 x Spring washers (M10)
* 4 x Flat washer (M10)

Tighten the bolt with a wrench, then proceed to the next step



5/16

Installation

Step 6: Connect the backrest (M14) to the three-headed lower connection frame (M2) by following method:

* 4 x Hexagon socket cheese head screws (M10)
* 4 x Spring washers (M10)
* 4 x Flat washer (M10)

Tighten the bolt with a wrench, then proceed to the next step

6/16

Installation

Step 7: Connect the back pad (M15) to the three-headed lower connection frame (M2) by following method:

* 4 x Hexagon socket cheese head screws (M10)
* 4 x Spring washers (M10)
* 4 x Flat washer (M10)

Step 8: Install the three-piece plate (M21) to the Triceps frame (M1).

7/16

Installation

Step 9: Attach two three-headed lower pressure handles (M20) to the three-headed lower pressure seat (M2) by following method:

Step 10: Connect the two-headed lower pressure bar with the two three-headed lower crimp handles (M1) by following method:

* 2 x Hexagon socket cheese head screws (M8)
* 2 x Spring washers (M8)

Tighten the bolt with a wrench, then proceed to the next step



8/16

Installation

Step 11: Connect the counterweight rubber pads (M26) onto the three-headed lower crimp frame (M1) by following method:

* 2 x Hexagon socket cheese head screws (M6)
* 2 x Flat washer (M6)

Tighten the bolt with a wrench, then proceed to the next step

9/16

Installation

Step 12: Slide the two counterweight rubber pads (M26) onto the two-headed lower crimp frame (M1) by following method:

Step 13: Connect the two 80 wire sheath (M16) to the counterweight frame (M3) by following method:

* 2 x Hexagon socket cheese head screws (M6)
* 2 x Hexagonal self-locking nuts (M6)

Step 14: Connect the two 80 wire sheath (M16) to the three-headed lower crimp frame (M1) and the three-headed lower connection frame (M2) by following method:

* 4 x Hexagon socket cheese head screws (M6)
* 4 x Hexagonal self-locking nuts (M6)

Step 15: Connect the two 80 kit wire rope (M22) to the counterweight frame (M3) and the three-headed lower pressure arm frame (M1) and the wire rope (M22) to the three-headed lower pressure arm frame (M1).

10/16

Installation

Step 16:Slide the two kits crimp (M40) into the two baffles (M39) and then connect the counterweight frame (M3) using the M10 connecting screws.

Step 17:Slide the two pulley (M42) into the two baffles (M39) and then connect the counterweight frame (M3) using the baffle pressure plate.

Attach the two upper shrouds (M43) to the counterweight frame (M3) by following method:

* 4 x Hexagon socket cheese head screws (M10)

Connect the upper shroud top cover (M45) to the two upper shrouds (M43).

Connect the two counterweight clear plug caps (M41) to the counterweight frame (M3) using the following method:

* 4 x Hexagon socket cheese head screws (M10)

11/16

Installation

12/16

Installation

Important notice

Use the CIRCLE to accurately, you must make sure your setup is level and correct before use. Ensure that the guide rods are vertical in both directions, fine frame hardware must be

13/16

Accessories List

No	Names and Specifications	Quantity
1	Three-headed lower crimp frame	1
2	Hexagon socket cheese head screws (M20*62)	4
3	Spring washers (20)	22
4	Flat washer (20)	22
5	Hexagon socket cheese head screws (M10*62)	24
6	Counterweight rack	1
7	Three-headed lower connection frame	1
8	Counterweight lower shroud	1
9	Hexagon socket cheese head screws (M10*52)	2
10	Counterweight frame (M3)	1
11	Flat Oval Foot Pad	2
12	Seats	1
13	Cushion	1
14	Hexagon socket cheese head screws (M8*62)	4
15	Spring washers (8)	4
16	Hexagon socket cheese head screws (M10*60)	2
17	Back pad	1
18	Hexagon socket cheese head screws (M8*40)	4
19	Backrest	1
20	Three-headed lower pressure arm	2

14/16

Accessories List

No	Names and Specifications	Quantity
21	Three downrest pressure handle	2
22	Limit sleeve	2
23	Universal counterweight guide bar	2
24	Counterweight rubber pad	2
25	Counterweight plate	1
26	Hexagon socket cheese head screws (M6*20)	4
27	Counterweight block	18
28	Guide block set	1
29	Hexagon socket cheese head screws (M6*16)	2
30	Counterweight plate	2
31	Wire rope	1
32	M Kits Misc1	1
33	Wire sheath 80	2
34	Flat washers (12)	5
35	Hexagonal self-locking nuts (M10)	5
36	120 wire sheath	2
37	Baffle	4
38	Counterweight upper decorative strip	1
39	Counterweight center decorative plate	1
40	Counterweight upper shroud	2
41	Top screw of upper shroud	2

15/16

Accessories List

No	Names and Specifications	Quantity
42	Counterweight clear plug cap	2

The actual quantity of parts may vary from the list due to the actual product.

16/16