Table of contents

Introduction ---------- 2
Assembly ---------- 3
Accessories List ---------- 10

1/16

Introduction

Please take the time to read this instruction carefully before installation. Please refer to the various links in the manual to confirm the integrity and quantity of all parts (if there are parts missing or damaged during transportation, please call our after-sales service immediately for instructions). Please install the equipment correctly according to the relevant instructions. This equipment is designed to provide the smoothest and most effective exercise. When installation, the used is authorized all functions to use it incorrectly. If you find any problems during use, you should stop using it immediately to avoid physical injury and equipment damage. Please refer to the relevant instructions in time to inquire about the cause. If you cannot solve it, please call our after-sales service. After reading all the instructions carefully, please continue

Rubber rod
Level
Hexagon wrench
Two people
Sterile gloves
Adjustable wrench

2/16

Assembly

Step 1: Connect the High Pull Connection Frame (M6) to the Counterweight Frame (M7) and Pull Pull Side Frame (M8) using the following method:
-Hexagonal socket head screw (M6)
-M8 Spring washer (M8)
-M8 flat washer (M8)
Step 2: Connect the connection plate (pivot M6) to the counterweight frame (M7) using the following method:
-Hexagonal socket head screw (M6)

Step 3: Install the two weights used here (M12) onto the weight rack (M7)
Install the two flat iron bars (M12) to the high pull side frame (M8)

3/16

Assembly

Step 1: Connect the left and right high pull arm (M10) and high pull seat (M9) to the high pull side frame (M8) using the following method:
-Hexagonal socket head screw (M6)
-M8 Flat washer (M8)
Tighten the bolts with a wrench before proceeding to the next step

4/16

Assembly

Step 1: Connect the left and right leg pressing plate (M11) to the counterweight frame (M7) using the following method:
-Hexagonal socket head screw (M6)
-M8 Spring washer (M8)
-M8 flat washer (M8)
Tighten the bolts with a wrench before proceeding to the next step



5/16

Assembly

Step 1: Connect the pedal (M5) to the seat (M10) using the following method:
-Hexagonal socket head screw (M6)
-M8Flat washer (M8)
Tighten the bolts with a wrench before proceeding to the next step



6/16

Assembly

Step 1: Connect the pedal (M5) to the high pull side frame (M8) using the following method:
-Hexagonal socket head screw (M6)
-M8Flat washer (M8)
-M8 Spring washer (M8)
Tighten the bolts with a wrench before proceeding to the next step

7/16

Assembly

Step 1: Connect the High Pull Cap Press Stand (M13) to the High Pull Side Stand (M8) using the following method:
-Hexagonal socket head screw (M6)
-M8Flat washer (M8)
-M8 Spring washer (M8)
Tighten the bolts with a wrench before proceeding to the next step

8/16

Assembly

Step 1: Install the M counterweight (M6) onto the guide rod (M6) with the smooth faces up.
Install the guide rod (M6) vertically (M12) onto the guide rod (M6)
Slide the guide bar attaching plate (M12) onto the guide bar (M6).
Connect the guide bar attaching plate (M12) to the counterweight frame (M7) as follows:
-Hexagonal socket head screw (M6)
Tighten the bolts with a wrench before proceeding to the next step

9/16

Assembly

Step 1A: Attach the two M3 wire cords (M15) to the counterweight frame (M7) using the following method:
-1*4.5mm (M4) 1.5L Hexagon self-locking nut (M4)
-Two 4.5mm (M4) flat washers (M4)

Attach the other M3 wire cord (M15) to the high pull side frame (M8) and the high pull linkage (M14) using the following method:
-M4 Nut (M4) M4 Hexagon self-locking nut (M4)
-Two M4 flat washers (M4) per connection
Note that these wires are connected simultaneously with the wire rope (M16).

Step 2A: Attach the M16 belt, end of the belt rope (M16) to the counterweight frame (M7).
Attach the M16 belt end of the wire rope (M16) to the high pull side frame (M8).

10/16

Assembly

Step 1A: Attach the two buffers (M18) to the counterweight frame (M7) using the buffer frame.
Attach the two buffers (M18) to the high pull side frame (M8) using the buffer frame (M7) using the buffer bolt-down plates.
Attach the two square pillows (M18) to the counterweight frame (M7) as follows:
-Hexagonal socket head screw (M6)

Attach the two counterweight guide rods (M12) to the counterweight frame (M7) using the following method:
-Hexagonal socket head screw (M6)



11/16

Assembly

Operation Tips
Now that the basic device has finished is assembled, the following is what we want to make sure what work to start and stops. Let the things hardware and assembled start tighten the bolts from time. At that are not stable, so may have to loosen some of

12/16

Accessories List

Serial number	Name and specification	quantity
1	Hexagon socket head screw M6X80	4
2	High pull top press	1
3	Hexagon socket head screw M6X40	12
4	Pivot bushing	4
5	Pivot bushing -02	16
6	Hexagon socket head screw M6X60	12
7	Counterweight rack	1
8	High pull connection frame	1
9	Counterweight frame assembly	1
10	Hexagon socket head screw M6X45	10
11	Weight rack flat plate	1
12	Flat seat foot pad	2
13	High pull rubber	2
14	High pull left armrest pad	1
15	High pull right pad	1
16	Hexagon screw cover	2
17	Pedal pad	2
18	Pedal	2
19	cushion	2
20	Hexagon socket head screw M8X65	2
21	Flat washer M8	4

13/16

Accessories List

Serial number	Name and specification	quantity
22	Hexagon socket head screw M6X50	2
23	High pull top press	1
24	Horizontal square guide rod	2
25	Hexagon socket head screw M8X60	2
26	Counterweight	16
27	Guide frame set	1
28	Side rod fixing plate	1
29	Counterweight rack	1
30	Seat frame back Main Pipe	1
31	M wire	2
32	Nut M4	2
33	Pivot bushing -03	2
34	Hexagon self-locking nut M6X	4
35	LAN rail	1
36	Nylon	2
37	Counterweight weight detection plate	1
38	Counterweight weight plate2	1
39	Upper guard cover	1
40	Counterweight plate cover	1

The accessories parts are not listed in this table.

14/16