H1618 Installation Guide
Standing Assisted Chin / Dip



catalog

Introduction 2

Assembly 3

Packing Details 12

1/12

Introduction

Please take the time to read these instructions carefully before installation. Please refer to the instruction manual to assemble.

It is recommended one to perform all assembly and to ensure any nuts and bolts are tightened before use.

Do not proceed to the other instructions. When installing, please install the equipment correctly according to the relevant instructions.

After the product is designed to provide the comfortable and most effective workout to exercise, promote, offer maximum safety.

Ideal for professional and for families to use it correctly. If you find problems during use, you should stop using it immediately.

Avoid unnecessary injuries and equipment damage. Are probably due to the relevant instructions to check the manual. If the problem

rubber mat

earth bolt

Allen wrench

Tool spanner

wrong plums

Adjustable wrench

Accessories

2/12

Step 1. Install the four foot pads (2) on the four pillows of the left frame (1) and the right frame (1).

Step 2. Use the following method to connect the backrest frame (1), left frame (2), right frame (3), and connecting frame (4).

M10*105 Hexagon socket head screws - 10

M10 Flat washer - 10

M10 Nylon lock nut - 10

Assembly the backrest frame, the main body

3/12

Assembly

Step 3. Connect the left armrest frame (1) to the left frame (2) using the three key methods

Use the same method to connect the right armrest frame (1) to the right frame (2).

M10*55 Hexagon socket head screw - 6

M10 Flat washer - 6

M10 Nylon lock nut - 6

Armrest to register the left frame and connecting the main body

4/12

Assembly

Step 4. Install the seat back (1) on the first pillow of the counterweight to seat frame (1), and fixed into a counter-weight frame bolt sleeve (2).

Step 5. Use the following method to connect the counter-weight frame (1) to the bottom frame (1) and counter-weight to the main frame

M10*55 Hexagon socket head screw - 2

M10 Flat washer - 2

M10 Nylon lock nut - 2

Counter-weight frame and the main frame and the seat to the left armrest and frame. (1) Screws 2)

M10*55 Hexagon socket head screw - 10

M10 Flat washer - 10

M10 Nylon lock nut - 10

Armrest to register the main frame and connecting to the main body

5/12

Assembly

Step 7. Use the following method to connect the handle frame (1) to the pull frame (1) and counter-weight frame (2) respectively.

M10*55 Hexagon socket head screw - 4

M10 Flat washer - 4

M10 Nylon lock nut - 4

Armrest to register the main frame and connecting to the main body

6/12

Assembly

Step 8. Install the counter-weight (1) into the guide rail (1) of the main weight frame (2), using the following method.

4 M8*16 Hexagon socket head screws (1)

Install the guide rail (1) into the main weight frame (2).

Step 9. Use the following method to connect the support frame (1) to the main weight frame (2) and the counter-weight frame (3).

4 M10*80 Hexagon socket head screws (1)

4 M10 Flat washers (2)

4 M10 Nylon lock nuts (3)

Armrest to register the main frame and connecting to the main body

7/12

Assembly

Step 10. Place the two curved installation pads (1) at second holes (2) of the counter-weight frame (1).

Step 11. Install the counter-weight (1B) onto the guide rail (1) of the main weight frame (2), using the following method.

Installing guide bolt sleeve (1A) and guide wheel (1C).

Insert the weight number (1D) into the weight rack (2).

Install the counter-weight (1B) onto the guide rail (1).

Install the guide bolt sleeve (1A) and guide wheel (1C) on the other side, using the following method.

4 M8*16 Hexagon socket head screws (1)

Install the guide bolt sleeve (1A) and guide wheel (1C) on the other side, using the following method.

8/12

Assembly

Step 12. Take the two L-shaped rubber mat (1) and fixed on the bottom (2A) and connect the two right frames (1) using the fender connector plate (2B).

Step 13. Use the following method to connect the two L-shaped rubber mat (1) to the right frame (2) using the fender clamps (2A).

Attach the L-type gasket (3C) to the angled frame, using: (1)

4 M8*16 Hexagon socket head screws (1) (2) (3)

9/12

Assembly

Step 14. Take the two L-shaped rubber mat (1) and fixed on the bottom (2A) and connect the two left frames (1) using the fender connector plate (2B).

Step 15. Use the following method to connect the two L-shaped rubber mat (1) to the left frame (2) using the fender clamps (2A).

Attach the L-type gasket (3C) to the angled frame, using: (1)

4 M8*16 Hexagon socket head screws (1) (2) (3)

10/12

Assembly

Step 16. Take the two L-shaped rubber mat (1) and fixed on the bottom (2A) and connect the two left frames (1) using the fender connector plate (2B).

Step 17. Use the following method to connect the two L-shaped rubber mat (1) to the left frame (2) using the fender clamps (2A).

Attach the L-type gasket (3C) to the angled frame, using: (1)

4 M8*16 Hexagon socket head screws (1) (2) (3)

11/12

Assembly

Aligned Insert Bolts

Note: Each Bolt Assembly Associated Should Not be Completely Set Level to make a element to adjust Horizontal Level. Please Check the Level Again After All Bolts Are Tightened. Make Sure All Bolts Are Tightened Before Use. Please Check Regularly Before Use and Tighten Any Loose Bolts. Failure to Do So Could Result in Serious Injury.

12/12

Standing Assisted Chin/Dip Packing list

Serial number	Name	Picture	Amount
1	chassis		1
2	left leaf		1
3	Right leaf		1
4	Connecting Frame		1
5	Seat plate		1
6	left armrest		1
7	Right armrest		1
8	Counter-weight rack plate		1
9	Pull frame		1

Serial number	Name	Picture	Amount
10	armrest bar		1
11	support frame		1
12	4.5/1.5KG		1

Serial number	Name	Amount
A	Hexagon socket head screw M10*55	26
B	Nylon lock nuts M10	10
C	Flat washer M10	10
D	Hexagon socket head screw M10*80	4
E	Hexagon bolt M10	4
M	Hexagon socket head screw M10*65	1

NOTE:The assembled parts are not listed in the table.