Brief ---------- 2

Installation ---------- 3

ccessories List---------- 13

Briefs

Please take the time to carefully read the instructions contained in this manual before you begin the installation. Check the list of all components were packaged well. (If there have some parts missed or damaged please immediately call our customer service department) Please refer to the installation instruction while installing.

This device designed to provide the most effective and smoothest training movements. After installing, you should check all the bolts, nuts, screws and other parts at the fastens. If there is any question, please check the installation instruction and find out the wrong steps during the installing. If still not work, please contact the distributors authorized by original factory. The code and manual will be needed.

Tools

Rubber stick

Levelling instrument

Socket head screw wrench

More than 2 person

Circlip pliers

The adjustable wrench

Installation

Step 1: Connect the abdominal attachment frame (M2) to the weight frame (M1) and the abdominal side frame (M3) using the following method

• 4 Hexagon socket cheese head screws (M4)

• 4 x spring washers (M5)

• 4 x flat washers (M6)

Step 2: Attach the abdominal linker II (M7) to the Abdominal Linker (M8) and the Abdominal Side Frame (M3) using the following method

• 4 x Hexagon socket cheese head screws (M4)

• 4 x spring washers (M5)

• 4 x flat washers (M6)

Step 3: Connect the counterweight lower shield (M9) to the counterweight frame (M1) using the following method,

• 2 x Hexagon socket cheese head screws (M4)

Step 4: Attach two weight rack feet (M10) to the weight frame (M1)

Install two flat oval foot pads (M11) to the abdominal side frame (M3)

Installation

Step 5: Attach the flange (M12) and 60-aluminum cap (M14) to the abdominal force arm (M13) using the following method

• 1 x Hexagon socket cheese head screws (M15)

• 1 x Spring washers (M2)

Tighten the bolt with a wrench, then proceed to the next step

Installation

Step 6: Attach the abdominal force arm (M12) and 76 aluminum caps (M16) to the abdominal muscles using the following method from 13 (M1).

• 1 x Hexagon socket cheese head screws (M15)

• 1 x Spring washers (M2)

Tighten the bolt with a wrench, then proceed to the next step

Installation

Step 7: Attach the ab press (M17) to the ab side rack (M3) using the following method,

• 2 x Hexagon socket cheese head screws (M4)

• 2 x Spring washers (M2)

• 2 x Flat washers (M6)

Tighten the bolt with a wrench, then proceed to the next step



Installation

Step 8: Attach the Abdominal Roll Pad (M18) to the Abdominal Side Brace (M3) using the following method.

• 2 x Hexagon socket cheese head screws (M19)

• 2 x Spring washers (M20)

• 2 x Flat washer (M21)

Tighten the bolt with a wrench, then proceed to the next step



Installation

Step 9: Attach the cushion (M22) to the abdominal side frame (M3) using the following method.

• 4 x Hexagon socket cheese head screws (M19)

• 4 x Spring washers (M20)

• 4 x Flat washer (M21)

Tighten the bolt with a wrench, then proceed to the next step



Installation

Step 10:Slide the two counterweight rubber pads (M24) onto the two guide bars (M23).

Connect the two counterweight bases (M25) to the two guide bars (M23) using the following method and put them into the counterweight frame (M1).

• 2 x Hexagon socket cheese head screws (M26)

• 2 x Spring washers (M20)

• 2 x Flat washer (M21)

Tighten the bolt with a wrench, then proceed to the next step

Step 11: Attach the 14 counterweights (M27) to the guide bar (M23) using the following method from 10 (M1).

Install the guide block set (M28) to the guide bar (M23).

Insert the counterweight block pins (M30) into the counterweight blocks (M27).

Slide the Guide Bar Retaining Plate (M29) onto the Guide Bar (M23), then secure the Guide Bar Retaining Plate (M29) to the Counterweight Frame (M1) using the following method.

• 2 x Hexagon socket cheese head screws (M26)

Tighten the bolt with a wrench, then proceed to the next step

Installation

Step 12: Connect the two 95 wire wheels (M32) to the counterweight frame (M1) using the following method.

• 2 x Wire spool (M32) • 2 x Hexagonal self-locking nuts (M33)

• 2 x Flat washer (M34) • 2 x Flat washer (M35)

Using the following method to thread the 120 line wheel (M36) Connect the abdominal muscle connection frame (M2) to the counterweight frame (M1).

• 1 x Wire axle (M32) • 1 x Hex self-locking nut (M33)

• 1 x Flat washer (M34) • 1 x Flat washer (M35)

Connect the two spool hoses (M37) and the 120 spool (M36) with the following method from 11 (M1).

• 2 x Wire spool (M32)

Note that these spools are installed in tandem with the wire rope (M31).

Step 13:Attach the end of the wire rope (M31) to the flange (M12) using the following method

• 1 x Flat washer (M34) • 2 x Socket (M38)

Step 14:Attach the bar nut (M40) to the ball end of the wire rope (M31). Attach the ball end of the wire rope (M31) to the counterweight frame center rod (M1).

Installation

Step 15:Slide the two trim strips (M42) into the two baffles (M41), using the baffle pressure plate to attach to the counterweight frame(M1). Slide the trim plate (M43) into the two baffles (M41) and use the baffle pressure plate to attach to the counterweight frame (M1).

Attach the two upper shrouds (M44) to the counterweight frame (M1) using the following method,

• 8 x Hexagon socket cheese head screws (M9)

Connect the top cover of the upper shroud (M45) to the two upper shrouds (M44).

Connect the two counterweight clevi plug caps (M46) to the counterweight frame (M1) using the following method,

• 2 x Hexagon socket cheese head screws (M9)

Installation

Important Notification

Now that the Abdominal Trainer is assembled, you'll need to check that the guide bars are perfectly plumb. To do so plumb, for a split level to check that the guide bars are perpendicular in both directions. Some framing hardware must be loosened to reassemble and bolts tightened if not plumb.

Accessories List

No.	Name & Specification	Qty.
1	Counterweight rack	1
2	Abdominal Joint Frame	1
3	Abdominal Side Frame	2
4	Hexagon socket cheese head screws (M20*M50)	14
5	Spring washers (M2)	16
6	Flat washer (M6)	14
7	Abdominal Movie connecting Frame II	1
8	Abdominal Linker (M8)	2
9	Hexagon socket cheese head screws (M20*M45)	2
10	Counterweight frame foot pads	2
11	Flat oval foot pad	2
12	Abdominal force arm	1
13	Abdominal force arm	1
14	60-Aluminum cover	1
15	Hexagon socket cheese head screws (M20*M20)	4
16	76-Aluminum cap	2
17	Abdominal top press rounder	1
18	Counterweight block pins	1
19	Hexagon socket cheese head screws (M4*45)	1
20	Spring washers (6)	8
21	Flat washers (6)	8

Accessories List

No.	Name & Specification	Qty.
22	Cushion	1
23	Universal counterweight guide bar	2
24	Counterweight Rubber Cushion	2
25	Counterweight base	2
26	Hexagon socket cheese head screws (M4*45)	4
27	Counterweight block	14
28	Guide block set	1
29	Guide Bar Retaining Plate	1
30	Counterweight block pins	1
31	Abdominal wire rope	1
32	95 wire wheel	2
33	Spool hex nut M12-2C	2
34	Flat washer (12)	2
35	Hexagonal self-locking nut (M10)	2
36	120 wire rope	1
37	Spool hub	2
38	Socket head (10)	2
39	Inner cord (M20*M45)	2
40	Hexagonal nut (M14)	1
41	Baffles	2
42	Counterweight source decorative strip	2

Accessories List

No.	Name & Specification	Qty.
43	Counterweight source decorative plate	2
44	Counterweight upper shroud	2
45	Upper shroud top cover	2
46	Counterweight clevi plug cover	2

Note: Pre-assembled parts are not listed in this table.