61820 Installation Guide
Multi Rig

Catalogue

Brief 2

Installation 3

Accessories List 15

Briefs

Please take the time to carefully read the instructions before installing.Please refer to the manual to determine the list of all components were packaged well, (If there have some parts missed or damaged please immediately call our after-service department).Please refer to the installation instruction while installing.

This device designed to provide the most effective and smoothest training movements. After installing, you can only know how to use the products after you have all the functions. If there is any question, please re-check the installation instruction and find out the wrong steps during the installing. If still not work, please contact the distributors authorized by original factory. The code and manual will be needed.

Tools

Rubber stick

Levelling instrument

Socket head screw wrench

More than 2 person

Circlip pliers

The adjustable wrench

Installation

Step 1: Connect the counterweight lower shield (#2) to the counterweight frame (#1) using the following method.

* 2 x Hexagon socket head screws (#3)

Step 2: Connect the Hip trainer bottom bracket (#4) to the counterweight frame (#1) using the following method.

* 4 x Hexagon socket cheese head screws (#6)
* 4 x Spring washers (#7)
* 4 x Flat washer (#8)
* 4 x Hexagon socket cheese head screws (#9)

Step 3: Install the 2 counterweight frame feet (#5) to the counterweight frame (#1).

Attach 2 flat feet (#5) each (#10) to hip trainer bottom bracket (#4)

Installation

Step 4: Connect the hip trainer main frame (#11) to the bottom bracket (#4) using the following method.

* 4 x Hexagon socket cheese head screws (#6)
* 4 x Spring washers (#7)
* 4 x Flat washer (#8)



Installation

Step 5: Connect the foot chock fixing screw (#12), hip trainer chain bar (#13), pedal holder assembly (#14), chain bar rubber pad (#15) to the bottom bracket (#4) using the following method.

* 4 x Hexagon socket cheese head screws (#6)
* 4 x Spring washers (#7)
* 4 x Flat washer (#8)

Step 6: Attach the hip trainer pedal frame assembly (#16) to the bottom bracket (#4) using the following method.

* 2 x Hexagon socket cheese head screws (#6)
* 2 x Spring washers (#7)
* 2 x Flat washer (#8)

Installation

Step 7: Connect the foot chock fixing screw (#12) to the hip trainer main frame (#11) using the following method.

* 2 x Foot chock (#17)
* 4 x Flat washer (#18)
* 4 x Nut self locking nut (#19)

Installation

Step 8: Connect the 2 pieces of air rod (#20) with the hip trainer main frame (#11) and pedal frame assembly (#16) respectively as shown in the picture.



Installation

Step 9: Connect the hip trainer handle frame (#30) to the hip trainer main frame (#11) and the hip trainer main frame (#11) using the following method.

* 4 x Hexagon socket cheese head screws (#6)
* 4 x Spring washers (#7)
* 4 x Flat washer (#8)
* 2 x Hexagon socket cheese head screws (#9)



Installation

Step 10: Connect the Hip Trainer Force Arm (#28), Hip Trainer Handle Bar (#29) to the Hip Trainer Handle Frame (#30), and Hip Trainer Main Frame (#11) using the following method.

* 1 x Hexagon socket flat countersunk head screws (#26)
* 1 x Hexagon socket flat countersunk head screws (#27)
* 1 x Hexagon socket flat countersunk head screws (#32)

Installation

Step 11: Slide the two counterweight rubber pads (#20) onto the two guide bars (#21).

Connect the two counterweight bumper (#22) to the two guide bars (#20) and place them in the counterweight frame (#1) using the following method.

* 2 x Hexagon socket cheese head screws (#11)
* 2 x Spring washers (#12) * 2 x Flat washer (#13)

Step 12: Connect the two counterweight rods (#23) to the pulley. Step 13: Install the 14 counterweight (#24) onto the guide bar (#20) with the isolation tube facing up.

Install the guide block set (#25) to the guide bar (#20).

Insert the counterweight block pin (#27) into the counterweight. Step 14:

Slide the guide bar resistor plate (#28) onto the guide bar (#20). Attach the guide bar fixing plate (#30) to the counterweight frame (#1) using the following method.

* 2 x Hexagon socket cheese head screws (#29)

Tighten the bolt with a wrench, then proceed to the next step

Installation

Step 15: Connect the two counterweight cables (#31) to the two counterweight rods (#23).

Connect the two counterweight boxes (#32) to the two guide bars (#20) and place them in the counterweight frame (#1) using the following method.

* 2 x Hexagon socket cheese head screws (#11)
* 2 x Spring washers (#12) * 2 x Flat washer (#13)

Step 16: Connect the two counterweight cables (#31) to the pulley. Step 17: Install the 14 counterweight (#24) onto the guide bar (#20) with the isolation tube facing up.

Install the guide block set (#25) to the guide bar (#20).

Insert the counterweight block pin (#27) into the counterweight. Step 18:

Slide the guide bar resistor plate (#28) onto the guide bar (#20). Attach the guide bar fixing plate (#30) to the counterweight frame (#1) using the following method.

* 2 x Hexagon socket cheese head screws (#29)

Tighten the bolt with a wrench, then proceed to the next step

Installation

Step 19: Connect the wire rope (#36) as shown, the pre-assembled spool (#35) and the tie rope (#34) to the counterweight frame (#1).

Attach the wire rope (#36) and installed in order #34,#35 the wire rope (#36) Connect one end of the wire (#36) to the winding reel (#21) and the other end to the counterweight frame (#1)

Installation

Step 20:Slide the two flat washers (#37) onto the two baffles (#38) and attach to the counterweight frame (#1) using the baffle pressure plate.

Attach the tie rubber (#41) into the two baffles (#38) and attach to the counterweight frame (#1) using the baffle pressure plate.

Attach the two spare shields (#42) to the counterweight frame (#1) using the following method.

* 4 x Hexagon socket flat countersunk head screws (#43)

Step 21: Connect the two counterweight cloze plugs (#42) to the counterweight frame (#1) using the following method.

* 4 x Hexagon socket flat countersunk head screws (#43)

Step 22: Snap the upper shroud top cover(#44) to the upper shroud(#42)



Installation

Important Notification

Now that the Multi Rig is assembled, you'll need to take a moment to make sure your unit is level and plumb. For a spirit level to work, it must be placed on a surface that is flat. Any adjustments to these framing hardware must be loosened to reasonable and hole tightened if not plumb.

Accessories List

No.	Name & Specification	QTY
1	Counterweight frame	1
2	Counterweight lower shield	1
3	Hexagon socket cheese head screws (M8*20)	12
4	Hip trainer bottom bracket	1
5	Hexagon socket cheese head screws(M8*60)	4
6	Spring washers (M8)	16
7	Flat washer (M8)	16
8	Hexagon socket cheese head screws (M8*40)	8
9	Counterweight frame foot pads	2
10	Foot chock fixing screw	2
11	Hip trainer main frame	1
12	Foot chock fixing plate	2
13	Hip trainer chain bar	1
14	Pedal frame assembly	1
15	Rubber pad for chain bar	1
16	Hexagon socket cheese head screws (M8*30)	4
17	Ergonomic self-locking nut (M8)	4
18	Air rod	2
19	Hip trainer upper support frame	1
20	Hip trainer force arm	1
21	Hip trainer handle bar	1

Accessories List

No.	Name & Specification	QTY
22	Hexagon socket flat countersunk head screws(M8*20)	4
23	Hexagon socket flat countersunk head screws(M8*25)	4
24	Hip trainer handle's bar	2
25	Hexagon socket set screw with tapered end(M8*8)	2
26	Hexagon countersunk head screw	2
27	Counterweight block pin	1
28	Counterweight bar	14
29	Guide bar fixing plate	2
30	Counterweight block plate	1
31	Counterweight cable	2
32	Counterweight box	2
33	Weight source decorative strip	1
34	Counterweight upper shield	1
35	Counterweight upper shield	2

Accessories List

No.	Name & Specification	QTY
36	Counterweight rubber pad	2
37	Spare shroud top cover	2

Note: Pre-assembled parts are not listed in this table.