C600 Installation Guide

Pectoral Fly / Rear Deltoid

Catalog

Brief Introduction ---------- 2

Assembly ---------- 3

Accessory List ---------- 13

1/16

Introduction

Please take the time to read these instructions carefully before installation. Please refer to the list in the instruction manual to confirm the completeness and quantity check of all parts. If any parts are missing or damaged in transit, please call our after-sales service immediately. When installing the equipment, please follow the relevant instructions to install the equipment correctly.

Please read the instructions to provide the smoothest and most effective workout. After installation, you need to understand all the functions in order to use it correctly. If the fitness club problems during use, you should stop using it immediately to avoid physical injury and equipment damage. And promptly refer to the relevant instructions to inquire about the causes, if you can not solve the problem, please call our after-sales service. After successfully reading all the instructions, please continue.

rubber mallet

level ruler

Allen wrench

Two people

carrying clamp

adjustable wrench

2/16

Assembly

Step 1:Attach the counterweight frame (1) to the lower shroud (6) with the counterweight foot (2) and secure with the following hardware:

- 2 M10*80Hexagon socket cheese head screws (13)
- Tighten the bolts with a wrench before proceeding to the next step

Step 2:Attach the Pectoral and Back Fly Unit Attachment Bracket (3) to the Counterweight Bracket (1) and attach the Fly Pad Rear Push (42) to.

- 4 M10*30Hexagon socket cheese head screws (9)
- 4 M10 Washer (10)
- 4 M10*30Flat set (11)

Tighten the bolts with a wrench before proceeding to the next step

3/16

Assembly

Step 3: Attach the Bronze and Back Fiber Side Frame (5 10) to the Bronze and Back Fiber Side Frame (5 10).

- 8 M10*80Hexagon socket cheese head screws (13)
- 8 M10Washing washer (9)
- 8 M10 Nylon nut (12)

Tighten the bolts with a wrench before proceeding to the next step

Step 4: Connect the Bronze and Back Fiber Side Frame (5 10) to the Bronze and Back Fiber Frame (7 10) and fasten with the following hardware:

- 4 M10*80Hexagon socket cheese head screws (13)
- 4 M10Washing nut (9)
- 4 M10 Nylon nut (12)

Tighten the bolts with a wrench before proceeding to the next step

4/16

Assembly

Step 5: Connect the left/right Flange (15 16) with the two force arms (18) and the two Handles (17) with the following hardware:

- 4 M10*80Hexagon socket cheese head screws (13)
- 4 M10Washing washer (9)
- 4 M10 Nylon nut (12)

Tighten the bolts with a wrench before proceeding to the next step

Step 6:Connect the cord end (20) to the pressure plate (21) by.

- 2 M10*30Flat set (11)
- 2 M10 Ball nut washer (22)

Tighten the bolts with a wrench before proceeding to the next step

5/16

Assembly

Step 7: Attach the two pressure fill from the previous step's assembly to the Chest and Back Fiber Side Frame (5 10).

- 4 M10*80Hexagon socket cheese head screws (13)
- 4 M10Washing washer (9)
- 4 M10 Nylon nut (12)

Tighten the bolts with a wrench before proceeding to the next step

6/16

Assembly

Step 8:Connect the two movable seats (23) and the two force arms (18) with the following hardware:

- 4 M10*80Hexagon socket cheese head screws (13)
- 4 M10Washing nut (9)
- 4 M10*30Flat washer (11)

Tighten the bolts with a wrench before proceeding to the next step

7/16

Assembly

Step 9: Attach the Seat Pads (24) to the Chest and Back Fiber Side Frame (5 10) by.

- 8 M10*80Hexagon socket cheese head screws (13)
- 8 M10Washing washer (9)
- 8 M10 Nylon nut (12)

Tighten the bolts with a wrench before proceeding to the next step

Step 10: Attach the cushion (25) to the seat frame (23) using.

- 4 M10*80Hexagon socket cheese head screws (13)
- 4 M10*30Flat washer (11)

Tighten the bolts with a wrench before proceeding to the next step

8/16

Assembly

Step 11:Move the pre-installed wire sheaves and install the wire rope C (28) and wire rope (2) (29) back to its original place after changing them around the wire sheave in the manner as shown in the figure below, with the node of wire rope C (28) connected to the left/right Flange (15 16).

Note:The installation process of attaching the two sheaves (27) to the Bronzehead Fiber Side Frame (5 10) is the same as attaching the two sheaves (27) to the connecting the Bronze Fiber C (26) to the Fore Base (7 10) with the Cable Sleeve Plate (26).

9/16

Assembly

Step 12: Place the pre-installed cable bar assembly (30) into the counterweight frame (1).

Install the 10-piece counterweight block (32) onto the guide bar (32) with the installed cable bar(no.30).

Install the guide block assembly (33) onto the guide bar (32).

Attach the guide bar assembly to the main frame (1) by the guide bar (32).

Attach the guide bar assembly pulley (31) to the counterweight frame (1) by.

- 2 M10*80Hexagon socket cheese head screws (13)

Install the counterweight block pins (34) into the counterweight block (32), note that when installing the counterweight block pins (34), the end of the wire rope C is the end that should be inserted into the pin (34) first.

Tighten the bolts with a wrench before proceeding to the next step

10/16

Assembly

Step 13:Slide the two Grip Strips (40) over the two Buffer (41) and use the Buffer Plates to attach to the Counterweight Rack (41).

Slide the Grip Strips (40) over the two Buffers (41) and use the Buffer Plates to attach to the Counterweight Rack (41).

Attach the upper shroud (6)(8) to the counterweight frame (1).

- 8 x Hexagon socket cheese head screws (M10)

Step 13: Attach the Top Cover Tow (6)(8) to the Counterweight Frame (1).

- 8 x Hexagon socket cheese head screws (M10)

11/16

Assembly

Step 14: Place the assembled trainer in the proper position.

12/16

Important Use

Now that the Pectoral Fly/Rear Deltoid is assembled, you need to take a moment to make sure that every bolt and plug has a corresponding nut and washer and that they are tightened in all directions. If it is not tested you must loosen some of the items hardware is reassembled and tighten the bolts.

13/16

Accessory list

no	Name and specification	QTY
1	Counterweight frame	1
2	Counterweight foot	1
3	Pectoral and Back Fly Unit Attachment Bracket	1
4	Spring nut (M10)	30
5	Flat nut (M10*80)	30
6	Counterweight lower shroud	1
7	Bronze and Back Fiber Front Frame (M10*80)	4
8	Side Frame C	1
9	Side Frame D	1
10	Bronze and Back Fiber Side Frame (M10*80)	14
11	Spring nut (M8)	6
12	Flat nut (M8*80)	12
13	Force arm	2
14	Back unit	2
15	Left Flange	1
16	Right Flange	1
17	grass handle	2
18	crank cushion	2
19	Bronze and Back Fiber Front Frame (M10*80)	4
20	Movement arm	2
21	Seat frame	2

14/16

Accessory list

no	Name and specification	QTY
22	Cushion	1
23	Bronze and Back Fiber Side Frame (M10*80)	2
24	Backrest	2
25	Bronze and Back Fiber Side Frame (M10*80)	2
26	Fiber plug	4
27	pass bar	2
28	Axle rod	2
29	pulley	2
30	Cable Sleeve	1
31	Guide bar assembly plate	1
32	Guide bar assembly	2
33	Guide Block Assembly (Bronze Rod)	1
34	Weight stack	10
35	Weight stack pin	1
36	Connecting strip	2
37	shield	1
38	Decorative plate	2
39	Lower shield	1
40	Bronze and Back Fiber Front Frame (M10*80)	2
41	counterweight fastener	2
42	Back Fiber Push Rod	2

The assembled parts are not listed in this table.

15/16