Low Row



Table of contents

Introduction ---------- 2

Assembly ---------- 3

Accessories List ---------- 10

Introduction

Please take the time to read this instruction carefully before installation. Please refer to the various lists in the manual to confirm the integrity and quantity of all parts (if there are parts missing or damaged during transportation, please call our after-sales service immediately for instructions). Please install the equipment correctly according to the relevant instructions. This equipment is designed to provide the smoothest and most effective exercise. After installation, you need to understand all functions to use it correctly. If you find any problems during use, you should stop using it immediately to avoid physical injury and equipment damage. Please refer to the relevant instructions in time to inquire about the cause. If you cannot solve it, please call our after-sales service. After reading all the instructions carefully, please continue

Rubber rod
Level
Hexagon wrench
Two people
Circlip pliers
Adjustable wrench

Assembly

Step 1: Assemble the left low pull footrest (M13), right low pull footrest (M14), and handlebar tray (M6) and

The low tension side front (M32) is connected:
• 6xHexagon socket head screw (M22) + 6 x Hexagon socket head screws (M11)
• 1xFlat washer (M9) + 4 x Flat Washers (M25)
• 6xHexagon self-locking nut (M30) + 6 x Spring Washers (M22)

Step 2: Use the following method to assemble the low-pull seat cushion (M15) and the flat seat foot pad (M12) and the low-pull side frame II (M11).

Connect it up:
•6xHexagon socket head screw (M10)
•6xSpring washer (M18)
•6xFlat washer (M26)



Assembly

Step 3: Install the lower guard (M2) to the counterweight frame (M4) using the following method, and then assemble the low tension
Connect the side frame assembly (M3) to the counterweight frame (M4):
• 4xHexagon socket head screw (M27)
• 4x Flat washer (M9)
• 4x Spring washers (M8) • 2 x Hexagon socket head screws (M23)
Install the 5 weight rack foot (M5) to the weight rack (M4)
Step 4: Install the Low Pull Weight Frame Left Support (M30) and the Low Pull Weight Frame Right Support (M40) to the Weight Frame (M1)

Connect it with:
• 6xHexagon socket head screw (M7)
• 8xSpring washer (M8)
• 6xFlat washer (M9)



Assembly

Step 5: Slide the two rubber weight pads (M20) onto the two side rods (M24).

Connect the two counterweight frame bases (M20) and the two side rods (M24) and place them into the counterweight frame (M1) in the following manner:
Connect it with:
•6xHexagon socket head screw (M27)
•6xSpring washer (M8)
•6xFlat washer (M9)
Tighten the bolts with a wrench before proceeding to the next step

Step 6: Install the 18 counterweight (M28) onto the guide rods (M24) with the spacers facing up.
Install the guide block assembly (M29) onto the guide rod (M24).
Insert the counterweight pin (M31) into the counterweight (M28).
Slide the guide bar retaining plate (M39) onto the guide bar (M24).

Install the guide rod fixing plate (M38) to the counterweight frame (M1) as follows:
•6xHexagon socket head screw (M27)
Tighten the bolts with a wrench before proceeding to the next step



Assembly

Step 7: First disassemble the pre-installed EG and 120 reels, insert the wire rope (M22) as shown in the figure, and then reinstall the reels.

Note that these reels are installed synchronously with the wire rope (M22).

Step 8: Connect one end of the wire rope (M22) to the handle assembly (M11) and the other end to the counterweight frame (M1).

Assembly

Step 9: Slide the two trim strips (M34) into the two fenders (M33) and attach to the counterweight frame (M1) using the fender hold-down plates.

Slide the trim plate (M35) into the two baffles (M33)
and attach to the counterweight frame (M1) using the baffle pressure plate.

Attach the upper guard (M36) to the counterweight frame (M1) as follows:
• 4 x(M)x16 hexagon socket head screws (M3)

Step 10: Attach the upper cover trim (M37) to the counterweight frame (M1) and snap the upper guard cover (M36) into place using the following method:

Into the upper shield (M36):
• 4 x(M)x16 hexagon socket head screws (M10)

Assembly

Important Tips

Now that the Low Row is assembled, you need to take a moment to make sure your unit is level and plumb. Use a level to check that the guide rods are plumb in both directions. If they are not plumb, you can adjust the front leveler of the frame hardware and reassemble and tighten the bolts.

Accessories List

NUM	Name and specifications	QTY
1	Counterweight rack	1
2	Counterweight lower guard	1
3	Hexagon socket head screw (M)x(6)	6
4	Weight rack foot pads	2
5	Low tension side frame I	1
6	Safety mat	1
7	Hexagon socket head screw (M)x(M25)	6
8	Spring washer (D)	18
9	Flat washer (D)	18
10	Hexagon socket head screw (M)x(40)	6
11	Low tension side frame II	1
12	Flat seat foot pad	1
13	Pull left pedal low	1
14	Pull right pedal low	1
15	Hexagon socket head screw (M)x(M15)	8
16	Hexagonal self-locking nut (M)(8)	6
17	Low-pull seat cushion	1
18	Hexagon socket head screw (M)x(60)	6
19	Spring washers (8)	6
20	Flat washers (8)	6
21	Low tension arm	1

Accessories List

NUM	Name and specifications	QTY
22	Low tension arm shaft	1
23	Low tension arm tie rod	2
24	Universal weight guide rod	2
25	Counterweight rubber pad	2
26	Counterweight rack base	2
27	Hexagon socket head screw (M)x(6)	4
28	Counterweight	16
29	Guide block set	1
30	Guide rod fixing plate	1
31	Counterweight latch	1
32	Wire Rope	1
33	Bezel	4
34	Counterweight decorative strip	2
35	Counterweight source decorative plate	1
36	Counterweight upper guard	1
37	Upper guard decorative plate	1
38	Upper guard cover	1

Note: Pre-assembled parts are not listed in this table.