# ZX885 Installation Guide
## Converging Independent Shoulder Press

### Catalog


Brief introduction ---------- 2

Assembly Diagram ---------- 13


1/14

## Brief introduction

Please take the time to read these instructions carefully before installation. Please refer to the list in the installation manual to confirm the completeness and quantity check of all parts.If any parts are missing or damaged in transit, you should call our after-sales service immediately.When assembling the equipment, please follow the instructions to install the equipment correctly.

This equipment is designed to provide the smoothest and most effective workout. Allow installation and need to understand all the functions in order to use it correctly. If you find any problems during use, you should stop using it immediately to avoid physical injury and equipment damage. And timely reference to the relevant instructions to inquire about the cause, if you can not solve the problem, please call our after-sales service. After carefully reading all the instructions, please continue

rubber mallet
horizontal ruler
Allen wrench
Tee service
spring clamp
adjustable wrench

2/14

## Assemble

Step 1: Placement of Seat Axis Seated Shoulder Push Side Frame Assembly (M)



3/14

## Assemble

Step 2:Assemble the Z Rectangular Pad Axle (M) with the Seat Axis Seated Shoulder Push Backrest Side Back (M) and secure them with Flanged Hex Lock Nuts (M8) in the Multi-Back (M). attach the Multi-Back (M) to the Lumbar Shaft using the following method.

1 X Z Rectangular Pad Axle (M)
1 X Flanged Hex Lock Nuts (M8)

Step 3: Attach the Seat Axis Seated Shoulder Push Side Back Assembly (M), Attachment Back (M), and Backrest Side Back (M) to the Seat Axis Frame.

1 X M10*M10Hexagon socket sleeve head screws (M)
1 X M10*65Allen washer (M)
1 X M10*M10Hexagon socket sleeve head screws (M)
1 X M10*M10Hexagon socket sleeve head screws (M)



4/14

## Assemble

Step 4:Attach the Seat Axis Seated Push Shoulder Side Frame Assembly (M) to the Seat Group Frame (M)(Z Rectangular Pad Axle (M)).

1 X M10*M10Hexagon socket sleeve head screws (M)
1 X M10*65Allen washer (M)
1 X M10*M10Hexagon socket sleeve head screws (M)

5/14

## Assemble

Step 5: Attach the Seat Pad (M)(L), Back Pad (M)(L) to the Seat Axis Seated Push Shoulder Side Frame Assembly (M) and Backrest Side Back (M).

4 X M8*20Hexagon socket head screws
4 X M8*20Allen washer (M)

Step 6: Attach the Z-(M)-Bar Plugs (M)(L) to the corresponding holes in the Seat Axis Seated Shoulder Push Backrest Side Frame (M).



6/14

## Assemble

Step 7:Connect the Seat Axis Seated Shoulder Push Right Force Arm (M)(R), Seat Axis Seated Shoulder Push Left Force Arm (M)(L) to the Seat Axis Seated Shoulder Push Side Frame Set (M) by using the following method.

1 X M10*M10Hexagon cap (M)(L)
1 X M10*M10Hexagon socket sleeve head screws(M)(R)
Note:For symmetrical construction on both sides.

7/14

## Assemble

Step 8: Connect the Seat Axis Seated Shoulder Push Right Force Arm (M)(R), and the Seat Axis Seated Push Shoulder Side Frame (M) to the Seat Axis Seated Shoulder Push Side Frame Set (M) by using the following method.

1 X M10*M10Hexagon socket sleeve head screws(M)(R)
1 X M10*65Allen washer (M)(R)



8/14

## Assemble

Step 9: Slide the two counterweight rubber pads (M)(L) and (M)(R) onto the guide rods (M)(L). Connect the two counterweight boxes (M)(L) to the two guide rods (M)(R) and place them in the counterweight boxes (M)(L).

2 X M8*20Hexagon socket head screws (M)(L)
2 X M8*20Allen washer (M)(L)
2 X M8*20Flat washer (M)(L)

Step 10: The Servo Arm is already factory-processing to the user step.

Step 11: Attach the Weight stack (M)(L) to the guide bar (M)(L) with the isolation tube (M)(L).

Install the guide bar (M)(L) into the guide bar (M)(L) and secure it with the M8*20Hexagon socket head screws (M)(L).
Attach the guide bar mounting plate (M)(L) to the guide bar (M)(L).
Attach the Weight stack (M)(L) to the guide bar (M)(L) with the Flanged Hex Lock Nuts (M8).
2 X M8*20Hexagon socket sleeve head screws (M)(L)
Connect the Servo Arm (M)(L) to the guide bar (M)(L) by the user step.

9/14

## Assemble

Step 12: Slide the two counterweight rubber pads (M)(L) onto the guide rods (M)(L). Connect the two counterweight boxes (M)(L) to the two guide rods (M)(R) and place them in the counterweight boxes (M)(L).

2 X M8*20Hexagon socket head screws (M)(L)
2 X M8*20Allen washer (M)(L)
2 X M8*20Flat washer (M)(L)

Step 13: The Servo Arm is already factory-processing to the user step.

Step 14: Attach the Weight stack (M)(L) to the guide bar (M)(L) with the isolation tube (M)(L).

Install the guide bar (M)(L) into the guide bar (M)(L) and secure it with the M8*20Hexagon socket head screws (M)(L).
Attach the guide bar mounting plate (M)(L) to the guide bar (M)(L).
Attach the Weight stack (M)(L) to the guide bar (M)(L) with the Flanged Hex Lock Nuts (M8).
2 X M8*20Hexagon socket sleeve head screws (M)(L)
Connect the Servo Arm (M)(L) to the guide bar (M)(L) by the user step.



10/14

## Assemble

Step 15:Slide the two Grip Bridge (M)(R) into the two Buffers (M)(R) and use the Buffer Plates to attach to the Counterweight Rack (M).

Slide the Grip Plate (M)(R) into the two Buffers (M)(R) and use the Buffer Plates to attach to the Counterweight Rack (M).

Attach the upper shroud (M)(R) to the counterweight frame (M).
1 X M8*20Hexagon socket sleeve head screws (M)

Step 16:Attach the Upper Shroud Set (M)(R) to the Counterweight Frame (M) and snap the Upper Shroud Top Cover (M)(R) into the Upper Shroud (M)(R).
1 X M8*20Hexagon socket sleeve head screws (M)(L)



11/14

## Assemble



12/14

Important Notes

Now that the Durable Press Fastening is complete, you need to take a moment to make sure that all of the bolts are tightened. Please check the pedal arm and backrest to both directions. If it is not vertical use short hammer some of the flange bushes to reposition and tighten the bolts.

13/14

## Accessory list

| NO. | Name and specification | QTY |
|---|---|---|
| 1 | Double Axis Seated Push Shoulder Side Frame Assembly | 1 |
| 2 | counterweight frame | 1 |
| 3 | Suspension Cone | 1 |
| 4 | inner shroud | 1 |
| 5 | Hexagon socket sleeve head screws (M)(R)(L) | 2 |
| 6 | counterweight footrest | 2 |
| 7 | Rectangular Pad Axle (M) | 1 |
| 8 | Hexagon socket sleeve head screws (M)(R)(L) | 8 |
| 9 | Locking washer (M) | 20 |
| 10 | Low washer(M)(R)(Q235) | 20 |
| 11 | Hexagon socket sleeve head screws(M)(R)(Q) | 4 |
| 12 | Seat frame | 1 |
| 13 | Hexagon socket sleeve head screws(M)(R)(Q) | 1 |
| 14 | Backrest | 1 |
| 15 | Headrest | 1 |
| 16 | Arrival plug | 4 |
| 17 | Hexagon socket sleeve head screws(M)(R)(Q) | 1 |
| 18 | Low washer(M)(R)(Q) | 2 |
| 19 | Double Axis Seated Shoulder Push Left Power Arm | 1 |
| 20 | Double Axis Seated Shoulder Push Right Power Arm | 1 |

14/14

## Accessory list

| NO. | Name and specification | QTY |
|---|---|---|
| 21 | ZX885Installation Guide | 1 |
| 22 | Hexagon socket countersunk head screws(M)(R)(Q) | 2 |
| 23 | Shaft sealed pad shoulder linkage connecting rod | 2 |
| 24 | guide bar | 2 |
| 25 | Counterweight rubber pads | 2 |
| 26 | Counterweight box | 2 |
| 27 | Hexagon socket sleeve head screws (M)(R)(Q) | 4 |
| 28 | Spring washer (M) | 4 |
| 29 | Weight stack | 1 |
| 30 | Guide bushing set | 1 |
| 31 | Guide bar mounting plate | 1 |
| 32 | Weight stack pin | 1 |
| 33 | cable | 1 |
| 34 | pedal | 2 |
| 35 | Decorative strip | 2 |
| 36 | Decorative plate | 2 |
| 37 | Upper shroud | 1 |
| 38 | Upper Shroud Top Cover | 1 |
| 39 | Tap cover tube | 1 |
| 40 | Hexagon socket sleeve head screws(M)(R)(Q) | 2 |

The accessorial parts are not listed in this table.

14/14