catalog

Brief introduction ---------- 2
assemble ---------- 3
accessory list ---------- 11

brief introduction

Please take the time to read this instruction carefully before installation. Please refer to the various lists in the manual to confirm the integrity and quantity of all parts.(2) Have the parts missing or damaged during transportation, please call our after-sales service immediately for repair or replacement. Please install the equipment correctly according to the relevant instructions.

(3) Please use the designed to provide the smoothest and most effective exercise. After installation, you need to understand all functions to use it correctly. If you find any problem during use, you should stop using it immediately to avoid physical injury and equipment damage. Please refer to the relevant instructions in time to inquire about the causes. If you cannot solve it, please call our after-sales service. After reading all the instructions carefully, please continue

Tool	rubber mallet
	level ruler
	hexagon wrench
	spring clamp
	adjustable wrench

Note: When assembling, two or more persons are recommended to operate

assemble

Step 1: Attach the Counterweight Lower Shroud (#2) to the Counterweight Frame (#1) by the following method:

• 2 x Hexagon socket sherbet head screws M10*25 (#63)

Step 2:Attach the Bottom Frame Assembly (#4) to the Counterweight Frame (#1) using the following method:

• 4 x Hexagon socket sherbet head screws M10*25 (#63)
• 4 x Flat washer M10-OD20 (#65)
• 4 x Flat washer M10-OD30 (#66)

Step 3:Attach the Cushion (#3) to the Base Assembly (#4) using the following method:

• 4 x Hexagon socket sherbet head screws M10*25 (#63)
• 4 x Flat washer M10-OD30 (#66)

Step 4:Attach the 2 Counterweight Rack Feet (#11) to the Counterweight Rack (#1).

Install 1 flat alligator foot pad (#12) to the base frame assembly(#4).

assemble

Step 1:Attach the Riser Assembly (#13) to the Base Assembly (#4) using the following method:

• 2 x Hexagon socket sherbet head screws M10*25 (#63)
• 2 x spring washer M10 (#67)
• 4 x Flat washer M10-OD30 (#66)

Step 2: Attach the Riser Assembly (#13) to the Counterweight Frame (#1) with the Upper Pivot Axle Assembly (#62):

• 4 x Hexagon socket sherbet head screws M10*25 (#63)
• 4 x spring washer M10 (#67)
• 8 x Flat washer M10-OD30 (#66)

Step 3: Attach the Lower Pivot Axle Assembly (#61) to the Riser Assembly (#13).

NOTE:The Upper Pivot Shroud (#60) needs to be slipped onto the Upper Pivot Axle Assembly (#62) first before performing the locking operation.

assemble

Step 1: Attach the Riser Assembly (#13) to the Counterweight Frame (#1) with 2 Connecting Rockers (#64):

• 4x4mmpan socket sherbet head screws M10*25 (#63)
• 4 x spring washer M10 (#67)
• 4x4cut washer M10-OD2-#67

assemble

Step 2: Attach the Adjustment Disk Cylinder Assembly (#17) to the Base Frame Assembly (#4) using the following method:

Step 3:Attach the High/Low Pull Pulley (#18), High/Low Pull Bracket (#19) to the Riser Assembly (#13) using the following method:

• 8 x Hexagon socket countersunk head screws M8*22 (#20)
• 8 x Flat washer M8-OD20-#68 M8*2 (#21)
• 8 x Spring washer M8 (#22)
• 8 x Flat washers M8-OD2 (#23)

assemble

Step 1:Attach the two Counterweight Block Rubber Pads (#32) onto the twin Rods Bars (#31).

Connect the two Counterweight Rods (#31) to the two guide rods (#24) and place them in the Counterweight rack (#1) as follows.

• 2 x Hexagon socket sherbet head screws M8*20 (#27)

• 2 x spring washer M8 (#28)
• 2 x Flat washer M8-OD2 (#29)
Tighten the bolts with a wrench before proceeding to the next step.

Step 2: Attach the 10 Counterweight Blocks (#30) to the Guide Rods (#24) with the isolation tube facing up.

The guide block set (#26) mounts to the guide bar (#24).

Insert the counterweight block pin (#25) into the counterweight block (#30).

Slide the guide bar retainer plate (#26) onto the guide bar (#24).

Attach the guide bar mounting plate (#21) to the counterweight frame (#1) to.

• 2 x Hexagon socket sherbet head screws M8*20 (#27)

Tighten the bolts with a wrench before proceeding to the next step

assemble

Step 3: Thread in the low pull wire rope set (#33) and high pull wire rope set (#34) as illustrated. Attach the low pull wire rope set (#33) to the Riser Assembly (#13) and pull assembly and attention to these wheels and the low pull wire rope set (#33) and the high pull wire rope set (#34) synchronization installation.

Step 4: Attach one end of the Low Pull Rope Set (#33) to the Riser Assembly (#13) and pull the other end.

Connect one end of the high pull wire rope set (#34) to the counterweight bracket (#1) of the stand assembly and pull out the other end.

Step 5: Connect the low pull rope set (#33) to the high pull rope set (#34) with the (28 chrom assembly (#35).

assemble

Step 1:Slide the two Grip Strips (#39) into the two Baffles (#36) and one the Baffle Plates to attach to the Counterweight Rack (#1).

Slide the Grip Plate (#38) into the two Baffles (#36) and use the Baffle Plates to attach to the Counterweight Rack (#1).

Attach the upper shroud (#40) to the counterweight frame (#1) to.

• 4 x M8*15 hexagon socket sherbet head screws (#41)

Step 2: Attach the Top Cover Grip (#40) to the Counterweight Rack (#1) to

• 4 x#M8#M8hagon socket sherbet head screws (#41)

assemble

Accessory list

NO	Name and specification	QTY
1	Counterweight frame	1
2	counterweight lower shield	1
3	Hexagon socket sherbet head screws (M10*65)	4
4	Chassis components	1
5	cushion	1
6	Hexagon socket sherbet head screws (M10*65)	10
7	spring washer (M10)	10
8	flat washer (M10-OD30)	20
9	Hexagon socket sherbet head screws (M8*65)	4
10	flat washer (M8-OD20)	8
11	counterweight footrest	2
12	flat alligator foot mats	2
13	Riser components	1
14	Upper arm assembly	1
15	Hexagon socket sherbet head screws (M10*60)	4
16	connection sheet	2
17	Adjustment Cylinder Assembly	1
18	High and low pull rope pulleys	2
19	High and low pull rope pulleys	1
20	Hexagon socket countersunk head screws (M8*22)	8
21	Hexagon socket sherbet head screws (M8*22)	2

no	Name and specification	QTY
22	spring washer (M8)	2
23	flat washer (M8-OD2)	2
24	guide bar	2
25	Counterweight rubber pads	2
26	Counterweight base	2
27	Hexagon socket sherbet head screws (M8*20)	4
28	spring washer (M8)	2
29	Guide block set	1
30	counterweight	10
31	Guide bar mounting plate	1
32	Counterweight block pins	1
33	low pull wire rope sets	1
34	High pull wire rope sets	1
35	28Cable Chrome Assemblies	1
36	baffle	4
37	decorative strip	2
38	decorative plate	1
39	Cover shield	1
40	Upper shroud trim	1
41	Hexagon socket sherbet head screws (M8*65)	4

Note: Pre-assembled parts are not listed in this table.