H1680 Installation Guide

Chest Press

Catalogue

Brief ~~~~~~~~~~~~~~~~~~~~~~~~~~ 2

Installation ~~~~~~~~~~~~~~~~~~~~~~~~~~ 3

Accessories List ~~~~~~~~~~~~~~~~~~~~~~~~~~ 16

1/16

Brief

Please take the time to carefully read the instructions before installing. Please refer to the manual to determine if all the parts are included before starting. If there has been some parts damaged or damaged,please immediately call our customer service department.Please refer to the Accessories List for the parts you need.

This device designed to provide the most effective and safe exercise for the user. Please read this manual carefully and learn how to use the products after you have all the parts. Please keep the manual properly. Please refer to the installation instructions and find out the wrong steps during the installing. If still not work, please contact the distributor or dealer for help. Warmly thanks for you.

Tools:

Rubber stick

Levelling instrument

Socket head screw wrench

More than 2 persons

Circlip pliers

The adjustable wrench

2/16

Installation

Step 1:set the side frame(NO.1)vertical to ground level:

3/16

Step 2:with the following method install connected frame (NO.)weight stack frame (NO.) and side frame (NO.):

4 x Pan socket head cap screw (M8)

4 x Flat washer (M8)

4 x Spring washer (M8) ~~~~~~~~~~~~~~~~~~~~~~~~~~ 4 x Flat washer (M8)

Connect the connected frame (NO.) to the side frame (NO.) weight stack frame (NO.) and side frame (NO.)

4 x Pan socket head cap screw (M12)

4 x Flat washer (M12) ~~~~~~~~~~~~~~~~~~~~~~~~~~ 4 x Flat washer (M12)

Install the flat seat footpad (NO.) to side frame groups (NO.)

4/16

Step 3:with the following method install cushion (NO.) and cushion frame (NO.):

4 x Pan socket head cap screw (M10)

4 x Flat washer (M10)

4 x Flat washer (M10)

Proceed to tighten the bolts before proceeding to the next step

5/16

Step 4:with the following method install cushion frame (NO.) with side frame (NO.):

4 x Pan socket head cap screw (M10)

4 x Spring washer (M10)

4 x Flat washer (M10)

Proceed to tighten the bolts before proceeding to the next step

6/16

Step 5:with the following method install head pad (NO.)back pad (NO.) and side frame (NO.)

4 x Pan socket head cap screw (M12)

Proceed to tighten the bolts before proceeding to the next step

Step 6:connect 2 back (NO.) to side frame 2 (NO.)

7/16

Step 6:with the following method install Chest press linkage frame (NO.) and side frame (NO.):

4 x Pan socket head cap screw (M12)

4 x Spring washer (M12)

4 x Flat washer (M12)

Proceed to tighten the bolts before proceeding to the next step

8/16

Step 7:with the following method install and connect (NO.) (NO.) and the following screw standard parts:

4 x Pan socket head cap screw (M8)

4 x Flat washer (M8)

4 x Flat Flat washer (M8)



9/16

Step 8:with the following method install arm movement (NO.) ,arm movement axis (NO.) and side frame (NO.):

4 x Pan socket head cap screw (M8)

4 x Flat washer (M8)

4 x Flat washer (M8)

Proceed to tighten the bolts before proceeding to the next step

10/16

Step 9:with the following method install two Chest push bar (NO.) ,arm movement group and Chest press linkage frame (NO.):

4 x Pan socket head cap screw (M8)

4 x Spring washer (M8)

4 x Flat washer (M8)

Proceed to tighten the bolts before proceeding to the next step

11/16

Step 10:install two weight stack footpad (NO.) to guide rod (NO.) 2 ,

Lock the weight stack pin (NO.) to the weight stack frame (NO.) with two guide rod (NO.) and then put long weight stack frame (NO.)

4 x Pan socket head cap screw (M8)

4 x Spring washer (M8) ~~~~~~~~~~~~~~~~~~~~~~~~~~ 4 x Flat washer (M8)

Proceed to tighten the bolts before proceeding to the next step

Note:Please refer to the following picture to install the guide rod and then Insert the weight stack pin (NO.)

Install weight stack group (NO.) to guide rod (NO.)

Insert weight stack pin (NO.) to weight stack (NO.)

4 x Pan socket head cap screw (M8) ~~~~~~~~~~~~~~~~~~~~~~~~~~ 4 x Flat washer (M8)

Install fixed guide rod to weight stack frame (NO.)

4 x Pan socket head cap screw (M8)

Proceed to tighten the bolts before proceeding to the next step

12/16

Step 11:with the following method install two Magnetic (NO.) to weight stack frame (NO.):

4 x pollie unit (NO.) ~~~~~~~~~~~~~~~~~~~~~~~~~~ 4 x Hexagon self-locking nut (NO.)

4 x Pan head screw (M5) ~~~~~~~~~~~~~~~~~~~~~~~~~~ 4 x Flat washer (M5)

with the following method install two Magnetic (NO.) to weight stack frame (NO.):

4 x pollie unit (NO.) ~~~~~~~~~~~~~~~~~~~~~~~~~~ 4 x Hexagon self-locking nut (NO.)

4 x Pan head screw (M5) ~~~~~~~~~~~~~~~~~~~~~~~~~~ 4 x Flat washer (M5)

Note:Read these pollie unit installation requirements with caution.(M40

Install the pollie unit (NO.) to the weight stack frame (NO.) with the pan head screw (M5) and then add M20 Nylon nut to fasten pollie unit (NO.)

13/16

Step 12:Use two diamond-in strips (NO.) slider into both bowls (NO.) ,and then connect to weight stack frame (NO.)

Use decorative strips (NO.) slider into both bowls (NO.) ,and then connect to weight stack frame (NO.)

with the following method install two shroud band (NO.) to weight stack frame (NO.):

4 x Pan socket head cap screw (M5)

put top cover of shroud band(NO.) to shroud band (NO.)

with the following method install two belt (NO.) to weight stack frame (NO.):

4 x Pan head cap screw (M5)

14/16

Important Notification

The Chest press has been assembled.You need to take the time to make sure that all the bolts are tightened.Please check carefully to check whether the guide bar perpendicular to the two directions.If not, you can use the rubber hammer to adjust.Please keep reasonable hardness and tighten the bolts.

15/16

Accessories List

NO.	Name & Specification	QTY
1	side frame	1
2	Hex socket head cap screw (M10*65)	16
3	Flat washer (M)	32
4	Hexagon self-locking nut (M10)	8
5	spring washer (M)	18
7	weight stack frame	1
8	connected frame	1
9	Pan socket head cap screw (M12*65)	8
10	weight stack frame long	1
11	Hex socket head cap screw (M12*45)	12
12	weight stack frame footpad	2
13	Flat seat footpad	2
14	cushion frame	1
15	cushion	1
16	Pan socket head cap screw (M8*65)	4
17	spring washer (M)	4
18	Flat washer (M)	8
19	Pan socket head cap screw (M10*65)	16
20	head pad	1
21	back pad	1

16/16

Accessories List

NO.	Name & Specification	QTY
22	Hex socket head cap screw (M8*40)	5
23	Shell	2
24	Chest press linkage frame	1
25		
26		
27	arm movement group	1
28		
29	arm movement axis (*4*M*20)	1
30	Pan washer (M)	2
31	Chest push bar	2
32	weight stack guide rod	2
33	weight stack rubber pad	2
34	weight stack frame bar	1
35	Hex socket head cap screw (M*65)	3
36	weight stack pin	1
37	guide weight stack group	1
38	weight stack shroud band	1
39	weight stack pin	1
40	cable	1
41	Magnetic	1
42	pollie unit (S)	4

17/16

Accessories List

NO.	Name & Specification	QTY
43	Flat washer (LS)	4
44	side frame group	1
45	(Shell)	
46	(back)	2
47	weight stack decorative strip	2
48	weight stack decorative piece	1
49	weight stack shroud band	1
50	weight stack shroud band fix cover	1
51	weight stack bolt	1

NOTE: Not accessible parts are not listed in this list.

18/16