Catalog

Brief Introduction ---------- 2
Assembly ---------- 3
Accessory List ---------- 23

1/24

Brief Introduction

Please take the time to read these instructions carefully before installation. Please refer to the list in the instruction manual to confirm the completeness and quantity check of all parts. If any parts are missing or damaged in transit, you should call our after-sales service immediately! When installing the equipment, please follow the instructions to install the equipment.

The equipment is designed to provide the smoothest and most effective workout. After installation, you need to understand all the functions in order to use it correctly. If you find any problems during use, you should stop using it immediately to avoid physical injury. Please contact our after-sales service in time to solve the problem. Improper operation of the equipment or the use of non-factory parts, please do not after-sales service, after carefully reading all the instructions, please continue

- rubber mallet
- horizontal ruler
- Allen wrench
- Two persons
- spring clamp
- adjustable wrench

2/24

Assembly

Step 1: Placement of Seat Axis Seated Shoulder Push Side Frame Assembly (M1)

3/24

Assembly

Step 2:Assembly the 2 Rectangular Pad Rods (M2) with the Seat Axis Seated Shoulder Push Column Side Base (M3) and secured them by 4 Round Head Hex Cap Bolt (M4) in the Weight Rack (M5), attach the Weight Rack (M5) to the Lower Seated (M6) using the following method.

4 M10*80Rectangular Pad Rod (M2)
4 M10*80Round Head Hex Cap Bolt (M4)

Step 3: Attach the Seat Axis Seated Shoulder Push Side Back Assembly (M1), Attachment Back Seated Shoulder Push Frame (M7), and Backrest (M8) using the following method.

4 M10*80Rectangular socket sleeve head screws (M9)
4 M10*80Flat washer (M10)
4 M10*80Nylon Lock Nut (M11)
4 M10*80Rectangular socket sleeve head screws (M12)

4/24

Assembly

Step 4:Attach the Seat Axis Seated Push Shoulder Side Frame Assembly (M1) to the Seat Group Assembly (M6) using the following method.

4 M10*80Rectangular socket sleeve head screws (M12)
4 M10*80Flat washer (M10)
4 M10*80Nylon Lock Nut (M11)

5/24

Assembly

Step 5: Attach the Head Rod (M13), Back Pad (M14) to the Seat Axis Seated Push Shoulder Side Frame Assembly (M1) using the following method.

4 M10*80Rectangular socket sleeve head screws (M15)
4 M10*80Flat washer (M16)

Step 6: Attach the 2-30*60Arm Frame (M18) to the corresponding holes in the Seat Axis Seated Shoulder Push Frame Side Frame (M1).

6/24

Assembly

Step 7:Connect the Seat Axis Seated Shoulder Push-Right Force Arm (M19), Seat Axis Seated Shoulder Push-Left Force Arm (M20), and the Seat Axis Seated Shoulder Push Side Frame Set (M1) by using the following method.

4 D-8.5*50Long Sleeve (M21) Bearing(M21)
4 M10*80Rectangular socket sleeve head screws(M22)
4 M10*80Rectangular socket sleeve head screws(M23)



7/24

Assembly

Step 8: Connect the Axis Axis Seated Shoulder Push-Right Force Arm (M19), and the Axis Axis Seated Shoulder Push-Left Force Arm (M20) and the Axis Axis Seated Shoulder Push Side Frame Set (M1) by using the following method.

4 M10*80Rectangular socket sleeve head screws (M12)
4 M10*80Flat washer (M10)
4 M10*80Nut washer (M11)

8/24

Assembly

Step 9: Slide the two counterweight rubber pads (M24) over the two guide rods (M25). Connect the two counterweight bases (M27) to the two guide rods (M25) and place them in the counterweight blocks (M26).

4 M10*80Rectangular socket sleeve head screws (M28)
4 M10*80Flat washer (M29)
4 M10*80Nut washer (M30)

Connect the Axis Axis to seventh-factory proceeding to the next step.

Step 10: Attach the Weight stack (M31) to the guide bar (M32) with the latchpin (M33).

Insert the guide bar (M32) into the guide bar (M25).

Attach the guide bar weighting plate (M34) to the guide bar (M32).

Attach the guide bar weighting plate (M35) to the guide bar (M32).

Finally, attach the Weight Stack Cover (M36) to the Weight Stack Frame (M5) by 4 M10*80Rectangular socket sleeve head screws (M37).

Connect the Axis Axis to seventh-factory proceeding to the next step.

9/24

Assembly

Step 11: Thread the wire rope (M38) as shown in the picture. Use pre-installed sleeves used to secure the wire rope.

Note that these sleeves are not used to counterbalance and will be used later (M39).

10/24

Assembly

Step 12:Slide the two Big Weight (M40) onto the two Baffles (M41) and use the Bolts Pieces to attach to the counterweight Rack (M42).

Slide the Side Plate (M43) onto the two Baffles (M41) and use the Bolts Pieces to attach to the counterweight Rack (M42).

Attach the upper shroud (M44) to the counterweight frame (M5) by.

4 M10*80Rectangle socket sleeve head screws (M45)

Step 13: Attach the Upper Cover (M46) to the counterweight Frame (M5) and snap the Upper Cover Buckle (M47) into the Upper Cover Buckle Slot (M48).

11/24

Assembly



12/24

Assembly

Now that the Shoulder Press Converging is assembled, you need to take a moment to make sure it is safe and ready for use. Please check that the guide rods are vertical to both directions. If it is not vertical, please loosen the screws and use the frame hardware to adjust and tighten the nuts.

13/24

Accessory List

NO.	Name and specification	QTY
1	Double-Axis Seated Shoulder Push Frame Assembly	1
2	counterweight frame	1
3	Suspension Cone	1
4	Lower shroud	1
5	Rectangle socket sleeve head screws (M8*65)	12
6	Counterweight footrest	2
7	Rectangular Pad Rod	4
8	Rectangle socket sleeve head screws (M8*65)	4
9	Locking washer (M8)	20
10	Flat washer(M8*20*2.0)	16
11	Rectangle socket sleeve head screws(M8*60)	4
12	Seat frame	1
13	Rectangle socket sleeve head screws(M8*65)	1
14	Backrest	1
15	Headrest	1
16	30*60cm plug	4
17	Rectangle socket sleeve head screws(M8*65)	4
18	Flat washer(M8*20*2)	4
19	Double-Axis Seated Shoulder Push-Left Power Arm	1
20	Double-Axis Seated Shoulder Push-Right Power Arm	1
21	50*80mm plastic ball bearings	4

13/24

Accessory List

NO.	Name and specification	QTY
22	M10*80Rectangular nut	4
23	Rectangle socket countersunk head screws(M8*65)	2
24	Plastic coated pull shackle (flange connecting rod)	2
25	guide bar	2
26	Counterweight rubber pads	2
27	Counterweight base	2
28	Rectangle socket sleeve head screws (M8*65)	4
29	Spring washer (M8)	4
30	Weight stack	16
31	Guide bolts set	1
32	Guide bar mounting plate	1
33	Weight stack pin	1
34	cable	1
35	pedal	2
36	Decorative strip	2
37	Decorative plate	2
38	Upper shroud	1
39	Upper Shroud Top Cover	1
40	Top cover trim	1
41	Rectangle socket sleeve head screws(M8*65)	1

The accessorial parts are not listed in this table.

14/24