



Before Installation

Before You Start

- 01 Read these instructions carefully before installation. Check the parts lists to confirm that all parts and quantities are complete. If any parts are missing or damaged in transit, contact after-sales service immediately. Assemble the equipment according to these instructions.

Tools Required

- Rubber Mallet
- Spirit Level
- Hex Keys
- Snap-Ring Pliers
- Adjustable Wrench
- 2 People

Fastener Reference



#51
Socket head cap screw
M10x60



#55
Flat washer M10-D50

#59
Spring washer M10



#52
Socket head cap screw
M10x70



#56
Flat washer M10-D30



#60
Hex lock nut M10




#53
Socket head cap screw
M10x20



#57
Flat washer M10-D20

Assembly

STEP 1



ACTION
Connect the left frame (#1) and right frame (#2) with two connecting frames (#3), then install four rectangular foot pads (#50) on the left frame (#1) and right frame (#2).

HARDWARE



#1 × 1
Left frame



#51 × 8
Socket head cap screw
M10x60



#2 × 1
Right frame



#55 × 8
Flat washer M10-D50



#5 × 2
Left lever arm assembly



#57 × 8
Flat washer M10-D20




#50 × 4
Rectangular foot pad



#60 × 8
Hex lock nut M10

STEP 2




ACTION

Connect the left frame (#1) and right frame (#2) with the lever arm support frame (#4).

HARDWARE

 #4 × 1 Lever arm support frame	 #57 × 4 Flat washer M10-D20	 #52 × 4 Socket head cap screw M10×70
 #60 × 4 Hex lock nut M10	 #55 × 4 Flat washer M10-D50	

STEP 3



ACTION


Install the left lever arm assembly (#5) and right lever arm assembly (#6) on the left frame (#1) and right frame (#2), then install four lever arm sleeve assemblies (#7) on the left lever arm assembly (#5) and right lever arm assembly (#6).

HARDWARE


 #5 × 1 Left lever arm assembly	 #53 × 4 Socket head cap screw M10×20	 #6 × 1 Right lever arm assembly
 #56 × 4 Flat washer M10-D30	 #7 × 4 Lever arm sleeve assembly	 #58 × 4 Spring washer M10
 #59 × 4 Spring washer M10		

FINAL CHECK

01 Assembly is complete. Check that the machine is level and plumb.



Exploded View



Parts List

NO.	PART / SPECIFICATION	QTY	NO.	PART / SPECIFICATION	QTY	NO.	PART / SPECIFICATION	QTY	NO.	PART / SPECIFICATION	QTY
1	Left frame	1	5	Left lever arm assembly	1	51	Socket head cap screw M10×60	8	56	Flat washer M10-D30	4
2	Right frame	1	6	Right lever arm assembly	1	52	Socket head cap screw M10×70	4	57	Flat washer M10-D20	12
3	Connecting frame	2	7	Lever arm sleeve assembly	4	53	Socket head cap screw M10×20	4	59	Spring washer M10	4
4	Lever arm support frame	1	50	Rectangular foot pad	4	55	Flat washer M10-D50	12	60	Hex lock nut M10	12