


61A46B • Multifunction Adjustable Bench

INSTALLATION MANUAL



Before Installation

Before You Start

- 01 Read this manual before installation. Check all parts and quantities before assembly.
- 02 Stop using the equipment if any problem occurs during use.
- 03 Important Notes: After assembly, check that the equipment is level and vertical.


Tools Required

- Rubber Mallet
- Spirit Level
- Hex Keys
- Snap-Ring Pliers
- Adjustable Wrench
- 2 People

Assembly Notes

Follow the instructions carefully to install the equipment correctly.

Assembly



STEP 1, 2 & 3

STEP 1

Attach the fixed-angle abdominal board base (#2) to the main frame assembly (#1).

HARDWARE

- Socket Head Cap Screw (M10×25) (#3)
- Spring Washer (10) (#4)
- Flat Washer (10) (#5)

STEP 2

Attach the support frame (#6) to the main frame assembly (#1).

HARDWARE

- | | | |
|-----|---------------------------------------|-----|
| × 4 | • Socket Head Cap Screw (M10×25) (#3) | × 4 |
| × 4 | • Spring Washer (10) (#4) | × 4 |
| × 4 | • Flat Washer (10) (#5) | × 4 |

STEP 3


Install four flat oval foot pads (#7) on the abdominal board base (#2) and support frame (#6).

HARDWARE

- | | | |
|--|---------------------------|-----|
| | • Flat Oval Foot Pad (#7) | × 4 |
|--|---------------------------|-----|

FINAL CHECK

- 01 Use a spirit level to check vertical alignment. If adjustment is needed, loosen frame hardware, reinstall and tighten bolts.



Parts List

NO.	PART / SPECIFICATION	QTY	NO.	PART / SPECIFICATION	QTY	NO.	PART / SPECIFICATION	QTY
1	Main Frame Assembly	1	4	Spring Washer (10)	8	7	Flat Oval Foot Pad	4
2	Fixed-Angle Abdominal Board Base	1	5	Flat Washer (10)	8			
3	Socket Head Cap Screw (M10×25)	8	6	Support Frame	1			